


# ASSEMBLY INSTRUCTIONS



## + Do Not Use Power Tools



## + Suggested Adults



### NOTE:

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

## 1 IMPORTANT SAFETY INFORMATION

**Do not** assemble the product if the parts arrived damaged.


**Do not** assemble if Hardware parts are missing.

## 2 IMPORTANT ASSEMBLY INFORMATION


Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

## + Parts Included


① Body (1 pc)




② Front leg frame (1 pc)




③ Back leg frame (1 pc)



④ Right arm (1 pc)




⑤ Left arm (1 pc)




## + Parts Included

A. Bolt  
Ø8x65mm (6 pcs)



B. Bolt  
Ø8x50mm (4 pcs)




C. Spring Washer  
Ø8xØ12mm (6 pcs)



D. Flat Washer  
Ø8xØ19mm (6 pcs)



E. Allen Key (1 pc)




F. Wooden Cap (4 pcs)




# ASSEMBLY INSTRUCTIONS


①



②




③



# ASSEMBLY INSTRUCTIONS

④

Step 3



⑤

