



ASSEMBLY INSTRUCTIONS

Futon

ASSEMBLY REQUIREMENTS

30 Minutes
Assembly Time
(Approximate)

2-Person
Assembly



Thank you for purchasing our product!

Please refer and use this assembly instruction to assemble the product.
Contact our customer service department in case there are any missing or damage parts or hardware.

We appreciate your business!

ASSEMBLY PREPARATION:

1. Remove all packaging materials, staples and packing straps from the carton.
2. Refer to Parts List and Hardware List and ensure they are complete before you start assembling.
3. Place all fabric parts on a clean, flat and soft surface (e.g. carpet or rug) to prevent fabric from getting ripped.

SAFETY PRECAUTION:

1. KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.
2. DISPOSE PLASTIC PACKAGING MATERIAL IMMEDIATELY TO AVOID ANY RISK OF SUFFOCATION TO CHILDREN AND ANIMALS.

TIPS FOR ASSEMBLY:

1. Allow ample room for assembly and in close proximity to where product will be placed.
2. Assemble the product on a surface that does not scratch or damage the fabric of the furniture.
3. Please check all of the parts and quantities are included before assembly.
4. Identify all of the parts, hardware and quantities required for each step.
5. During assembly, do not over-tighten any fittings as this may cause damage.
6. DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.
7. Always place the product on a flat, stable surface.
8. Do not sit or stand on the partially assembled product; only use the product for which it is intended.

CARE AND MAINTENANCE

- Use a slightly damp cloth to clean the product. Do not use bleach or abrasive cleaning material.
- Check all the fittings periodically and re-tighten as necessary. Do not use the product if any of the parts is damaged or broken.


This product is for indoor and household use only - not for commercial use.

ASSEMBLY INSTRUCTIONS


Futon

Parts List


Futon x1



Back Cushion x1



A. Legs x4




Hardware List

B. Allen Key x1




C. Screw x16pcs





STEP 1

Remove Back Cushion and box containing hardware under the Back Rest section of the furniture.



STEP 2 - Assemble Legs



- Place the futon as shown on a material that does not damage or stain the fabric.
- Align screw holes on the leg bracket to the screw holes on the base plate at the bottom-side of futon. (Note: The legs should angle outwards. The rear leg brackets are to be aligned squarely to each rear corner and the front leg brackets are to be aligned diagonally to each front corner.)
- Use Allen Key (B) to drive and tighten Screw (C) in a clock wise direction to fasten the legs to the bottom of futon base.

The assembly of the futon is complete.


ASSEMBLY INSTRUCTIONS

Futon


Using the Futon as a Couch



Place the furniture right-side up from STEP 2 as shown.




Bring the Back Rest to a vertical position towards the seat.




Put Back Cushion in place.

Using the Futon as a Couch


Step A
Set aside Back Cushion.




Step B
Open the zipper on the Seat to access legs. Pull-out the legs in the direction as shown to set legs in a vertical position.




Step C
Pull back to unfold and lay the Seat flat to rest on the legs.



Step D
Open the zipper on the Back Rest to access legs. Pull out the legs in the direction as shown to set legs in a vertical position.



Step E
Push down the Back Rest backwards to set the Back Rest flat down to rest on the legs



Step F
Put the Back Cushion in place.
The futon Bed is set.

