








ASSEMBLY INSTRUCTIONS

NIGHTSTAND

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

- 1 We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly
 - 2 Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
 - 3 Please do not over-tighten screws or bolts
 - 4 Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently
- . Do not allow children to climb on furniture.
 - . Do not place television sets on top of chest, door chest, and/or dressers.
 - . Please place heaviest objects on the lowest drawers.
 - . Please have no more than one drawer open at a time.

No	Parts List	Q'ty	Hardware List				
A		Nightstand	1 Pc	1		Bolt (Ø5/16" x 100mm)	4 Pcs
				2		Spring washer (Ø5/16"x13x1.2)	4 Pcs
				3		Flat washer (Ø5/16"x16x2)	4 Pcs
				4		Allen Key M4 x L100 mm	1 Pc
B		Legs	4 Pcs	5		Straight Allen Key M4 x L100	1 Pc

