

至善质量 至心服务  
Perfect quality , caring service  
至诚至信 至臻至美  
Good faith , Enjoy Perfect Life



# 使用说明

## INSTRUCTION

## 主要功能

全电子防雷功能          免提功能  
来电最后一组重拨功能

## 安装使用说明

- 1、将物品包装里的支架按方向放置在电话顶端的轴芯上，并用配置的螺丝固定方向
- 2、将电话机配置的直线一端接当地电信局安装的信号插孔另一端接电话机底部较大的话机插孔
- 3、将手柄上的曲线接电话机底部较小的插孔

## 拨打电话机

- 1、提起手柄或按下免提键，此时手柄听筒或喇叭出现嘟嘟的拨号声
- 2、听到拨号音后就可以开始拨号，将手指插入所要拨打号码的圆孔内顺时针旋转，直至RD按键并且把RD按键拨动，在听筒或喇叭里能听到拨号的音频声音后表示该号码拨出。
- 3、号码拨出后松开手指，使拨号盘自动返回到原来的位置再进行下一个号码的拨出，如此类推直至将所有的号码全部拨完
- 4、如拨完后对方无法接通或正在通话时需重新拨号，此时可直接按RD按键进行重拨

## 简易故障排除方法

- 1、无声：检查二芯直线插头与接线盒是否接触良好
- 2、杂音：检查电话线是否有松动，脱皮现象，接线盒是否生锈
- 3、电话铃声只响一声即断，但可拨号，检查接线盒是否进水潮湿或所接分机太多

## Instruction

### Main functions:

Thunder-proof  
Hands-free with calling  
The last coming numbers Re-dial

### Installation & USD

1. Taking out the supporting of telephone and putting it on the top of phone, then using the screw which we prepared for you fixes and the direction.
2. Install the telephone line to the native telephone company's signal jack, then install the big jack at the bottom of telephone.
3. Finally attaching the winding telephone cord to the smaller jack at the bottom of the telephone.

### Direction of call:

- a. Pick the phone up or press the < hands-free >, and then you can hear the beep sound from the telephone receiver or loudspeaker.
- b. You can start the report after you hear the dial tone and please insert your finger into the round hole to dial the number and then spin clockwise to the < RD > and toggle it. When you hear the audio sound in the receiver or loudspeaker, it means that the number is allocated.

### Direction of call:

- c. After the number is dialed, release the finger, to make the dial plate automatically return to the original location and dial out the next number and so on until all the numbers are set.
- d. Provided that after you finish the dialing, the other party can not be connected or he or she is talking on the phone, which leads to redialing, you can press the <RD> directly to redial.

## 保修须知

### 尊敬的用户:

感谢购买并使用至臻古典电话机，为了使我们的服务让您更加满意，购买后请认真阅读此保修卡并妥善保管。

- 1、此保修卡为质保凭证，必须有最终直接销售商的加盖印章。
- 2、自购买之日起，本公司负责保修一年，对机件的正常损坏，公司进行维修。
- 3、用户在保修期内，如发现任何质量问题，可凭发票及本保修卡到销售商或本公司维修点维修。

### 下列范围不属于免费保修范围

- 1、超过三保有效期的；
- 2、未按产品使用说明有要求、维护、保管而造成的损坏；
- 3、非承担三包与维修者拆动而造成的损坏；
- 4、无有效三包凭证及发票的（能够证明该三包有效期内的除外）；
- 5、擅自涂改三包凭证的；
- 6、三包凭证上的产品型号或编号与商品不相符合的；
- 7、因不可抗力造成的损坏。


## 保修卡

产品名称		产品型号	
产地	<b>中国东莞 Dongguan China</b>	销售商名称	
销售商电话		邮编	
销售商地址			
销售日期	年 月 日	发票号	
以上资料由销售商填写（并在此加盖销售商印章）			
消费者名称		联系电话	
地址		邮编	
以上资料由消费者填写			

此卡为产品保修凭证，须妥善保存；请仔细阅读背面保修条例

## 话机功能演示

Telephones s functions ration



NOTE: This description is just fo demonstrating product, it does not meaning the package alone with that telephone.