

ASSEMBLY INSTRUCTIONS



END TABLE

REVISION 0 : 08/19/2026

PAGE 1 OF 5

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME 25 MINUTES

PARTS IDENTIFICATION

A


TOP



1PC

B


LEG FRAME 1



1PC

C

LEG FRAME 2



1PC


ASSEMBLY INSTRUCTIONS

Z

HARDWARE IDENTIFICATION

1

CAM-BOLT
(38mm)



14PCS

3

ALLEN WRENCH
(4mm)



1PC


2

CAM-LOCK
($\phi 15\text{mm}$)




14PCS

STEP 1




STEP 2




ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4

COMPLETE



ASSEMBLY INSTRUCTIONS



Note : Dimension tolerance $\pm 5\%$