



ASSEMBLY INSTRUCTIONS




+Parts Included

① Legs (2 pcs)



② Seat frame (1 pc)



+Do Not Use Power Tools



+Suggested Adults



NOTE:

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

1 IMPORTANT SAFETY INFORMATION


- Do not** assemble the product if the parts arrived damaged.
- Do not** assemble if Hardware parts are missing.

2 IMPORTANT ASSEMBLY INFORMATION

Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

+Parts Included

A. Bolt
Ø8x65mm (10 pcs)




B. Spring Washer
Ø8xØ13mm (10 pcs)




C. Flat Washer
Ø8xØ19mm (10 pcs)



D. Dowel
Ø10x30mm (4 pcs)




E. Allen Key (1 pc)



ASSEMBLY INSTRUCTIONS

①



②

