









USER'S MANUAL









Folding Desk

PRODUCT ASSEMBLY


Hardware List

A	 Hinge	8 pcs	D	 Screw 4*40mm	12 pcs	G	 Plastic Anchor	6 pcs
B	 Screw 3*14mm	48 pcs	E	 Bolt	4 pcs	H	 Wood Dowel 8*30mm	4 pcs
C	 Screw 4*25mm	2 pcs	F	 Flat Washer	4 pcs			

Parts List


1	 Front Top Panel	1 pc	5	 Bottom Rail	1 pc
2	 Middle Top Panel	1 pc	6	 Triangle	1 pc
3	 Back Top Rail	1 pc	7	 Vertical Wall Rail	1 pc
4	 Slide Holder	2 pcs	8	 Back Wall Rail	1 pc

Part List Assembly Overview



PRODUCT ASSEMBLY

Step 1




- a) Place Top Panels (1 & 2) and Back Top Rail (3) tidily as shown.
b) Attach the Hinge (A) to the designated holes on (1, 2 & 3) by using Screw (B).

A		6 pcs
B		36 pcs

Step 2


- a) Attach Bottom Rail (5) to (2) by using Wood Dowel (H) and Screw (C).



- b) Attach Slide Holder (4) to (2) by using Flat Washer (F) and Bolt (E).

C		2 pcs
E		4 pcs
F		4 pcs
H		2 pcs

Step 3




- Attach Back Wall Rail (8) to Vertical Wall Rail (7) by using Screw (D). Do not overtighten.

D		2 pcs
---	--	-------


Step 4

- Attach Back Wall Rail (8) to (3) by using Wood Dowel (H) and Screw (D). Do not overtighten.



D		4 pcs
H		2 pcs

Step 5




- a) Attach Hinge (A) to Triangle (6) by using Screw (B).
b) Attach (6) to (7) by using Hinge (A) and Screw (B).

A		2 pcs
B		12 pcs

Step 6

- a) Drill the holes on a dry wall as per dia of Plastic Anchor (G) and the distance of the designated holes on (7 & 8).
b) Press Plastic Anchor (G) to the wall. Ensure that the Anchor fits securely in the wall.
c) Attach the unit to the Anchor by using Screw (D).





D		6 pcs
G		6 pcs



PRODUCT ASSEMBLY

Step 7



Adjust the place of Slide Holder (4) and Triangle (6) to meet the function you need.



Slide out Slide Holder (4) and Place Triangle (6) in side, you can fold both Top Panels as shown.



Slide in Slide Holder (4) and Place Triangle (6) in middle, you can fold Front Top Panel as shown.



Slide out Slide Holder (4) and Place Triangle (6) in middle, both Top Panels will be expanded as shown.