
ASSEMBLY INSTRUCTIONS


ITEM NO. FB3069HAY-SC-4PK




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.


Part List

NO.	DIAGRAM	PART NAME	Q'ty
#1		Back frame with cushion	1pc x4
#2		Seat frame with cushion	1pc x4
#3		Front Legs	2pc x4


Part List

NO.	DIAGRAM	PART NAME	Q'ty
#A		Bolt 1/4" x 3"	4pcs x4
#B		Bolt 1/4" x 2-1/4"	4pcs x4
#C		Bolt 1/4" x 1-1/2"	2pcs x4
#D		Spring washer Ø1/4"	10pcs x4
#E		Flat washer Ø1/4"	10pcs x4
#F		Allen key M4	1pc x4


x 4



STEP 1:




STEP 2:




Do not tighten screws until completely asembled.

STEP 4:



STEP 5:



Tighten all screws until completely asembled.