


Owner Manual



MAINTENANCE AND WARNINGS

Thank You For Choosing Our Furniture.


Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.

NOTE :


This brochure contains IMPORTANT safety info. Please read and keep it for future reference.



Weight Limitation
80 LBS



Installation:
55 minutes.



Two Person



Before You Start

Please follow the steps below:



Unbox the package and check if all parts and accessories are complete.



If you find something missing, stop assembly and contact your supplier immediately.



Please do not completely tighten all the hardware until the entire assembly is completed! Be sure to tighten all the hardware once the assembly completed.



NOTE: Should be assembled on soft surface to keep balance.

After-Sales Service

- If you encounter any issues or need technical support during use, please contact our after-sales team. We offer long-term maintenance and warranty services.



Warranty



We strive to offer high , quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.



Are you having difficulty with assembly? Missing parts? Please send email with your order number





For return, please check the return policy with the retailer or market place you bought from. Appreciate your purchasing from us. Pop up your life by our furniture piece!

Daily Maintenance


- Keep furniture away from heat.
- Do not use cleaning agents containing acids, alkalis, or corrosive substances, as they may damage the surface. It is recommended to use neutral cleaning agents or specialized furniture cleaners.
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, for residential use only.

Exploded Diagram




Parts List (Carton A)

A ×1




Top Panel

B ×1




Bottom Panel

C ×1




Left side Frame

D ×1




Right side Frame

E ×1




Front Rail

F ×1




Back Rail 1

G ×1




Back Rail 2

H ×1




Socket Mounting Board

I ×1




Back Panel

J ×2




Leg

K ×1




Left Side Drawer (top)

L ×1




Right Side Drawer (top)

M ×1




Top Panel Drawer (top)

N ×1




Left Side Drawer (bottom)

O ×1




Right Side Drawer (bottom)

P ×1




Bottom Panel Drawer (bottom)

R ×1




Front Panel Drawer (top)

S ×1



Front Panel Drawer (bottom)

T ×1



Back Panel Drawer (top+bottom)

Hardware List (Carton A)

1 ×22+2



screw Ø4*25mm

2 ×14+1



screw Ø3*15mm

3 ×2



screw Ø3*12mm

4 ×8+1




Bolt Ø1/4"*3/4"

5 ×8+1



Bolt Ø1/4"*3/4"

6 ×4



Bolt Ø1/4"*1-1/2"

7 ×12+1




Spring washer
Ø1/4"

8 ×12+1




Flat washer
Ø1/4" *16*1.2mm

9 ×4



Metal plate

10 ×1




Electrical socket

11 ×1



Pan head screw
Ø3.5*16mm

12 ×1



Pan head screw
Ø3.5*38mm

13 ×1



Anchor

14 ×2




L bracket

15 ×1




Metal wire

16 ×1



Allen key
M4

17 ×1





Screwdriver

Assembly Instructions

Step 1



Connect part (G) to part (F) with screw (1), tight screw with screwdriver (17).

1	 x 2	Ø4*25mm
17	 x 1	Screwdriver



Step 2


Insert panel (A) into panel (C), make sure all holes aligned and then tighten it with allen key (16) as picture show.



Note:
The allen wrench must be keep at a 45 degree Angle to the panel A .

Step 3


Insert panel F&G into panel C, make sure all holes aligned and then tighten it with allen key (16) as picture show.



Step 4

Insert panel (E) into panel (C), make sure all holes aligned and then tighten it with allen key (16) as picture show.

16	 X 1	M4
----	---	----



Step 5


Insert side panel (D) into the corresponding hole of preassembled step 4 , make sure all holes aligned and use allen key (16) to tighten it as picture show.

16	 X 1	M4
----	---	----



Note:


The allen wrench must be keep at a 45 degree Angle to the panel A .



Step 6

connect panel (B) to panel (C/D) with bolt (6), spring washer (7) and flat washer (8), tight bolt with allen key (16) .


6	 x 4	Ø1/4"*1-1/2"
7	 x 4	Ø1/4"
8	 x 4	Ø1/4" *16*1.2mm
16	 x 1	M4



Step 7

Insert back panel (1) into the groove of preassembled step 6, make sure all holes aligned and use screw (2) to attach them, tighten screw (2) with screwdriver (17).


2	 x 14	Ø3*15mm
17	 x 1	Screwdriver



Step 8

Connect part (9) to part (J) with part (4), tight bolt with allen key (16).


4	 x 8	Ø1/4"*3/4"
9	 x 4	Metal plate
16	 x 1	M4



Step 9

Connect part (J) to part (B) with bolt (5), spring washer (7) and flat washer (8),tight bolt with allen key (16).



5	 x 8	Ø1/4"*3/4"
7	 x 8	Ø1/4"
8	 x 8	Ø1/4" *16*1.2mm
16	 x 1	M4



Step 10

Connect part (H) to part (G/F) with screw (1), tight screw with screwdriver (17).





1	 x 4	Ø4*25mm
17	 x 1	Screwdriver




Step 11

Connect part (10) to part (H) with screw (3), tight screw with screwdriver (17).



10	 x 1	Electrical socket
3	 x 2	Ø3*12mm
17	 x 1	Screwdriver



Step 12




Attention:
Before the next step, adjust the
feet of the locker to keep it level.




Step 13

Connect part (K/L) to part (R) with screw (1) and tighten it with screwdriver (17).
Slide in the part (M) into the groove of part (K/L). make sure they are also in groove in part (R).


1	 x 4	Ø4*25mm
17	 x 1	Screwdriver




Step 1



Step 2




Step 3



Step 14

Connect the (T) to (L/K) with screw (1) , and tighten it with screwdriver (17).


1	 x 4	Ø4*25mm
17	 x 1	Screwdriver




Step 15

Connect part (N/O) to part (S) with screw (1) and tighten it with screwdriver (17).
Slide in the part (P) into the groove of part (N/O). make sure they are also in groove in part (S).


1	 x 4	Ø4*25mm
17	 x 1	Screwdriver




Step 1



Step 2




Step 3



Step 16

Connect the (T) to (O/N) with screw (1) , and tighten it with screwdriver (17).


1	 x 4	Ø4*25mm
17	 x 1	Screwdriver





Step 17



Attention:
When installing the drawer,
slide the steel ball slide rail of side
panel to the most front as picture show.




**Schematic diagram of
slide rail disassembly**



Step 18

Use screw (11) to attach part (13) to top panel (A),tighten screw (11) with screwdriver (17).



14	 x 1	L bracket
11	 x 1	Ø3.5*16mm
17	 x 1	Screwdriver




Step 19

Install Anti-tip device (14) to the wall in this step.


13	 X 1	Anchor
14	 X 1	L bracket
12	 X 1	Ø3.5*38mm
17	 X 1	Screwdriver



1. Drill a hole in the wall with an electric drill.



2. Tap the plastic wall anchor (13) into the hole with a hammer.



3. Secure the Anti-tip device (14) to the wall with screws (12)

Step 20

15	 x 1	Metal wire
----	---	------------

⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on any drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.



***This is a permanent label.
Do not remove!***

