

BRIGHTECH

Allure LED Floor Lamp

Assembly Instructions for the BrightechAllure LED Floor Lamp:

After removing all parts from packaging, simply place the lamp in the desired location. Plug Power Supply Adapter(B) into connector on lamp Head (A) first, then into outlet, and power on!

Operations and Features:

The Allure is controlled via a three step foot pedal/on/off switch foot pedal located on the power supply cord. Simply tap the button to turn on and cycle through the dimmer settings. It can be turned on and off via a wall switch for convenience, but it cannot be dimmed except by the touch sensor on the lamp.

When using the lamp with a wall switch, it will remember its settings: if you turn the switch off with the lamp set to a lower brightness level, it will stay on the same lower level when you turn the switch back on.

Thank you for purchasing this product!

We offer a three year warranty on manufacturing defects. Proof of direct purchase from Brightech or purchase in new condition from one of our authorized sales partners is required for all warranty requests. Coverage starts from purchase date, and is not transferable. If you experience an issue with your product, please reach out to us via our website and we will be happy to assist you.

Extend Your Warranty, Free:

Purchases from brightech.com come with an automatic 5-year warranty. All other verified, non-solar Brightech purchases come with an automatic 3-year warranty and offer a complimentary warranty extension option. If you would like to extend your warranty coverage period to 5 years from the date of purchase, fill in this short product registration form on our site: <https://brightech.com/pages/extended-warranty>.

