
ASSEMBLY INSTRUCTION



Installation:
Use the provided wall mount. Ensure the wall is free of hidden electrical, water, or gas pipes before drilling.
When installing with power tools please use a low speed setting.
Wear gloves to avoid getting lubricant on your hands.











Tips before you start：
1.Double check that all parts and hardware are included before starting.
2.Install on a soft surface (rug or blanket) to avoid scratches.
3.Pay attention to the orientation of all holes and grooves.
4.Insert screws vertically, incorrect angle can cause damage to the panel.
5.Tighten screws only 50%, and then fully tighten them after ensuring everything is correct

Stability:
Never allow children to climb or hang on the unit. Do not place a TV or heavy objects on top unless specifically designed for it.



Usage:
Place the heaviest items in the bottom drawers/shelves.
Do not open more than one drawer at a time.





Parts & Safety:
This product contains small parts. Keep all small parts and plastic bags away from children to avoid suffocation or fatal hazards.




PARTS




1		1 PC
2		1 PC
3		1 PC
4		1 PC
5		1 PC
6		1 PC
7		2 PCS
8		1 PC
9		6 PCS
10		3 PCS
11		1 PC
12		3 PCS
13		2 PCS
14		1 PC



PARTS

A		B		C		D	
		 Ø12		 Ø6×30		 M3.5×10	
26	PCS	26	PCS	7	PCS	64	PCS


E		F		G		H	
 M3.5×16							
18	PCS	4	PCS	8	PCS	8	PCS

I		J		K		L	
							
2	PCS	6	PCS	1	PC	2	PCS

M		N		O		P	
 M3.5×14							
6	PCS	6	PCS	1	PC	2	PCS


Q		R						
		 R1 R2		 R3 R4 R5 R6				
2	PCS	3	PCS					

PARTS




step1/step18


	A×10
R3 R4	R×3



step2/step18


	A×10
 R3  R4	R×3







step3/step18

	B×12










step4/step18

	B×8
	C×4









step5/step18


	N×6






Need to bring your own hammer


step6/step18




step7/step18

	A×6
	D×6
	I×2
	O×1










step8/step18


	B×6
	C×3







step9/step18

	D×24
	J×6
	M×6









step10/step18

	P×2


step 1




step 2




step 3




step 4






step11/step18


	D×18
	E×6
 R1  R2	R×3







×3

step12/step18

	E×6
	F×3
	G×6







×3


step13/step18


R5	R6	R×3






step14/step18


	E×6




Easily adjust the shelf up or down in two fixed positions, or remove it entirely to accommodate high-top shoes and bulky items.



step15/step18









step16/step18


	D×4
	F×1
	G×2
	L×2



step17/step18

	D×8





step18/step18

	D×4
	Q×2

