


Assembly Instruction Sheet for Model HL579254

Package Contents

Part	Description	Quantity
A	Mounting Bracket	1 pc.
B	Antler Fixture Arm	multi pcs.
C	Fixture Body	1 pc.
D	Lamp Support	1 pc.
E	Chain	1 pc.
F	Ceiling Canopy	1 pc.



STEP 1

Mark the drilling position on ceiling with the help of the Mounting Bracket(A).
Drill holes on the marks and stick the expansion anchors into the holes.
Fix the Mounting Bracket(A) to the expansion anchors with self-tapping screws.

STEP 2

Thread the wire of Antler Fixture Arm(B) to the hole of Fixture Body(C),
and screw the Antler Fixture Arm(B) to the Fixture Body(C).
Thread the wire of Antler Fixture Arm(B) to the hole of Lamp Support(D),
and screw the Antler Fixture Arm(B) to the Lamp Support(D).
Repeat the above step to fix the other Antler Fixture Arms(B).

STEP 3

Thread the wire of Lamp Support(D) to the Fixture Body(C),
and screw the Lamp Support(D) to the Fixture Body(C).

STEP 4

Connect wire color Black/Red from the Fixture Body(C) as one strand of wire.
Connect wire color Blue of Fixture Body(C) as the other strand.

STEP 5

Fix the Chain(E) to the hole of Fixture Body(C), and screw the Chain(E) to the hole of Ceiling Canopy(F).
Hold the fixture close to ceiling.
Connect live line to wire color Black/Red from the canopy of Fixture Body(C).
Connect neutral line to wire color White/Blue from the the canopy of Fixture Body(C).

STEP 6

Attach the Ceiling Canopy(F) to the Mounting Bracket(A).

STEP 7

Insert your bulb to the bulb base.

Your fixture is now assembled and ready to use.