

## Model: HFTP-111BK

**Multi-functional and professional mobile stand  
For TV panels: 32"-70"**

**Maximum load capacity: 110 lbs /50 kg**

**AV shelf max load: 10 lbs / 4.5kg**

**VESA: 200X200-600X400mm**

### WARNING!




























Severe personal injury and property damage can result from improper installation or assembly. Read the following warning carefully before beginning.

- If you do not understand the instructions or have any concerns or questions, please contact a qualified local installer.
  - Do not install or assemble if the product or hardware is damaged or missing; if you require replacement parts, please contact your local distributor for assistance.
  - This product fits most 32"-70" LCD/plasma screen; maximum weight of LCD/plasma screen: 110 lbs/50kg; AV shelf max load: 10 lbs/4.5kg.
  - Do not use this product for anything other than the original design.
  - This product contains moving parts, please use with caution.
  - The manufacturer disclaims any liability for the modifications, improper installation, or installation over the specified weight range. The manufacturer will not be liable for any damages arising out of the use of, or inability to use, the product.
- All images are for reference, to prevail in product.


### Manual

Tightening Direction	Loosening Direction	Phillips Screwdriver	Metre Rule	Adjustment	By Hand	Hex Wrench


## Parts List

1X A3 		1X C3 		1X D3 		
1X B3 						
1X E3 	1X F3 	1X G3 	1X H3 	1X I3 	2X J3 	4X K3 
					4X L3 	1X M3 
A1 4X  M4×12mm	B1 4X  M5×25mm	C1 4X  M6×25mm	D1 4X  M8×25mm	E1 4X  Φ16×Φ6.2×1.5mm	F1 4X  Φ19×8.5×H13mm	G1 2X  Φ8×17×1.5mm
A2 6X  M8×26mm	B2 4X  M8×55mm	C2 2X  M5×12mm	D2 1X  Φ16.5×Φ12.5×2mm	E2 4X  Φ16.5×Φ12.5×2mm	F2 1X  M6	G2 1X  M5

### 1. Castor wheels to base installation




### 2. Post assembly to base installation




### 3. Install telescopic mounting poles

Step 1. Use thumb or finger to depress the right upper pole spring plunger ball. Located at the cable window, twist and pull upper pole upward until your desired height. Shown in fig-1 twist upper pole toward the plunger holes direction and engage the spring ball into the plunger hole and set as shown in fig-2.


Step 2. Repeat step 1 for left pole




### 4. AV shelf assembly and installation




### 5. Installation of interface




6. Selection of TV mounting patterns



7. Mounting TV on pole interface



8. Cables and wires installtion



9. Product specifications

