


# Dog Crate




Model: WF323362AAE


---

PRODUCT GUIDE AND INSTALLATION MANUAL

# Parts List:




Ⓐ x1 (Left Side Frame)




Ⓑ x1 (Right Side Frame)




Ⓒ x6 (Metal Rail)



Ⓓ x1 (Left door)




Ⓔ x1 (Right door)



Ⓕ x1 (Plate)

## Parts List:



Ⓒ x1 (Top Panel)



Ⓓ x1 (bottom Panel)



Ⓘ x1 (Back Panel)



Ⓙ x1 (Upper Shelf Trim)



Ø1/4"x45mm

Ⓚ x12



Ø1/4"x22mm

Ⓛ x12




Ø1/4"x30mm

Ⓜ x12



Ø1/4"

Ⓝ x4



Ⓞ x4




M3x12mm

Ⓟ x20




M3x12mm

Ⓠ x8



M4x30mm


Ⓡ x2



Ⓢ x1




Ⓣ x1




Ⓤ x1

# STEP 1

1.1




1.2




## STEP 2

2.1




2.2




### STEP 3



3.1



3.2




## STEP 4




## STEP 5

5.1




5.2




# STEP 6

6.1




6.2



# STEP 7

7.1



7.2

