




INSTALLATION

Product Manual




IMPORTANT INFORMATION!

Please read the entire manual before starting to assemble and/or using this product. Follow the manual thoroughly and keep it for further reference.





AVOID SCRATCHES!

In order to avoid scratching this furniture should be assembled on a soft layer-could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !






It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability through-out the lifespan of the product.

For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag. For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.

Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.



Please prepare the following tools




When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 152



CRB1595A

B x 150




CRA0635B

C x 100



CRF0630A

D x 150



E x 128




CRD3512A

F x 116



CRD3514A

G x 48




CRC0540A

H x 113



CRE0316A

J x 12



DGA861C

K x 72




L x 12




CRD3520A

M x 2




N x 10



P x 2




Q x 24



CRE0418A

R x 6



S x 12




CRD3525A


T x 41



U x 2



V x 2




W x 2




CRD3535A

X x 2




Y x 2












Z x 6




AA x 2







x6










⚠ WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:




- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.



*This is a permanent label.
Do not remove!*






1

E x 4  CRD3512A	CL x 1  WX1014A	CR x 1  WX1014A	
--	--	--	---






Secure slide rail (CL) and (CR) to panel 10 and 4 using screws (E).

- Please note that the positions of the screws for these two sliding rails are different.




2


E x 4  CRD3512A	CL x 1  WX1014A	CR x 1  WX1014A	
--	--	--	---

Secure slide rail (CR) to panel 26 using screws (E).

Flip the same board to the other side, and secure slide rail (CL).




- Please note that the positions of the screws for these two sliding rails are different.



3

E x 8  CRD3512A	CL x 2  WX1014A	CR x 2  WX1014A
--	--	--








Secure slide rail (CL) to panel 27 using screws (E).




Flip the same board to the other side, and secure slide rail (CR).



- Please note that the positions of the screws for these two sliding rails are different.




4


E x 8  CRD3512A	CL x 2  WX1014A	CR x 2  WX1014A	
--	--	--	---

Secure slide rail (CL) to panel 28 using screws (E).


Flip the same board to the other side,
and secure slide rail (CR).





- Please note that the positions of the screws for these two sliding rails are different.



x2




flip



x2





5

B x 12






CRA0635B




D x 12



Install plug (D) into panel 8 and 14,
then screw self-tapping rod (B) onto.





6



A x 2  CRB1595A	C x 2  CRF0630A	M x 2 	AC x 2 	
--	--	--	---	---


Put nut (AC) and screw threaded rod (M) into panel 8.

Connect panel 8 to panel 14 using wooden dowel (C), then tighten by turning cam lock (A) clockwise.




7

A x 12  CRB1595A	C x 12  CRF0630A	
---	---	---




Connect panel 4, 27, 28 and 10 to panel 8 and 14 using wooden dowel (C), then tighten by turning cam lock (A) clockwise.



8


F x 8

CRD3514AAD x 2
E

CRD3512AF


CRD3514A

Secure bracket (AD) to panel 8 and 26 using screw (F).








9

B x 20






CRA0635B

D x 20



Install plug (D) into panel 15 and 16,
then screw self-tapping rod (B) onto.




10

C x 12






CRF0630A


G x 12




CRC0540A



Connect panel 15 and 16 to panel 4, 28, 27 and 10 using wooden dowel (C), then secure with screw (G).




11


F x 8  CRD3514A	AD x 2 	
--	---	---

	E  CRD3512A	F  CRD3514A
---	--	--


Secure bracket (AD) to panel 16 and 26 using screw (F).



12





Install plug (D) into panel 3 and 9,
then screw self-tapping rod (B) onto.




13

A x 8
CRB1595A





Connect panel 3 and 9 to panel 33 and 34, then tighten by turning cam lock (A) clockwise.




14

A x 8
CRB1595A




Connect panel 3 and 9 to panel 33 and 34, then tighten by turning cam lock (A) clockwise.




15


AA x 2



AE x 2



Secure the two components using screw (AA).







16


A x 20




CRB1595A







Connect the component to panel 15 and 16, then tighten by turning cam lock (A) clockwise.



17



Install plug (D) into panel 1, 2 and 25,
then screw self-tapping rod (B) onto.









18

B x 24






CRA0635B

D x 24



Install plug (D) into panel 24, then screw self-tapping rod (B) onto.




19

A x 11









CRB1595A


C x 8



CRF0630A







Connect panel 2 and 24 to panel 17, 22 and 37 using wooden dowel (C), then tighten by turning cam lock (A) clockwise.





20




Install plug (D) into panel 24, then screw self-tapping rod (B) onto.




21






Connect panel 24 to panel 17, 22 and 37 using wooden dowel (C), then tighten by turning cam lock (A) clockwise.



22



Install plug (D) into panel 24, then screw self-tapping rod (B) onto.




23

A x 11







CRB1595A


C x 8




CRF0630A





Connect panel 25 and 24 to panel 17, 22 and 37 using wooden dowel (C), then tighten by turning cam lock (A) clockwise.



24



Install plug (D) into panel 25, then screw self-tapping rod (B) onto.




25

A x 11









CRB1595A



C x 8



CRF0630A







Connect panel 25 and 24 to panel 17, 22 and 37 using wooden dowel (C), then tighten by turning cam lock (A) clockwise.



26



Install plug (D) into panel 24, then screw self-tapping rod (B) onto.




27

A x 11







CRB1595A



C x 8



CRF0630A







Connect panel 24 to panel 17, 22 and 37 using wooden dowel (C), then tighten by turning cam lock (A) clockwise.



28



Install plug (D) into panel 24, then screw self-tapping rod (B) onto.




29

A x 11









CRB1595A



C x 8





CRF0630A




Connect panel 1 and 24 to panel 17, 22 and 37 using wooden dowel (C), then tighten by turning cam lock (A) clockwise.





30



Connect panel 35 to panel 36 using dowel (C).




31

F x 16  CRD3514A	X x 2 	
---	--	---

	E  CRD3512A	F  CRD3514A
--	--	--

Secure iron sheet (X) to panel 35 and 36 using screw (F).




32

B x 12








CRA0635B




D x 12






Flip the panels over, install plug (D) into panel 35 and 36, then screw self-tapping rod (B) onto.




Flip to back




33

A x 12  CRB1595A	C x 12  CRF0630A	G x 12  CRC0540A	
---	---	---	---



Connect panel 35 and 36 to panel 37, then tighten by turning cam lock (A) clockwise.

Connect panel 35 and 36 to panel 1, 24 and 2 using wooden dowel (C), and secure with screw (G).




34

E x 32



CRD3512A

N x 4



Secure bracket (N) to panel 11 and 35, panel 5 and 36 using screw (E).



E





CRD3512A

F



CRD3514A




35

E x 48



CRD3512A

N x 6



E




CRD3512A

F




CRD3514A

Secure bracket (N) to panel 12 and 36, panel 6 and 36 using screw (E).




36




F x 12  CRD3514A	P x 2 	V x 2 	AB x 1 	
---	--	--	---	---

	E  CRD3512A	F  CRD3514A
--	--	--

Secure part (AB) to panel 6 and 12 using screw (F).
 Secure part (P) to panel 5, 6, 11 and 12 using screw (F).
 Secure part (V) to panel 35 and 36 using screw (F).



37




38

S x 12



CRD3525A



L





CRD3520A

S



CRD3525A

Secure panel 8 and 14 to panel 17 using screw (S).




39

H x 113




CRE0316A

T x 41



Secure back panel 31, 29, 30 and 32 to the cabinet using screw (H) and part (T).





40

L x 12



CRD3520A

Y x 2



L




CRD3520A

S




CRD3525A


Secure part (Y) to backplate 29 and 32 using screw (L).




41

U x 2 	W x 2  CRD3535A	
--	--	---


Install the anti-tip device as shown.




1.





2.




3.



4.




42

F x 24  CRD3514A	J x 12  DGA861C	
---	--	---

	E  CRD3512A	F  CRD3514A
---	--	--

Secure hinge (J) to panel 21 using screw (F).




43


F x 48



CRD3514A



E




CRD3512A

F



CRD3514A

Secure panel 21 to the cabinet using screw (F).





44

Q x 12




CRE0418A

R x 6



Secure handle (R) to panel 21 using screw (Q).





45


K x 72




Insert pin (K) into panel 1, 2, 24 and 25.




OR




OR



46




Place panel 23 into the cabinet.




47



G x 24



CRC0540A



Secure panel 7 and 13 to panel 18 using screw (G), then insert panel 19 along the available slots.









48

B x 24




CRA0635B



D x 24



Install plug (D) into panel 20, then screw self-tapping rod (B) onto.



x6




49

A x 24









CRB1595A


C x 12




CRF0630A





Connect panel 20 to panel 7 and 13 using wooden dowel (C), then tighten by turning cam lock (A) clockwise.



x6




50


E x 24  CRD3512A	DL x 6  WX1014A	DR x 6  WX1014A	
---	--	--	---

	E  CRD3512A	F  CRD3514A
---	--	--


Secure slide rail (DL) and (DR) to panel 13 and 7 using screw (E).




51


Q x 12  CRE0418A	Z x 6 	
---	--	---


Secure pull handle (Z) to panel 20 using screw (Q).





Install the drawers as shown.









If doors are not aligned, please adjust the screws on the hinge according to your own situation by referring to the illustration below.





I




II




III





I




II




III



I



II



WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.
- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.
- The product must be used in accordance with the instructions provided. For health reasons.
- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.
- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.
- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.
- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOUR ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.