





















User's Manual




















PRODUCT PARTS:


A	B	C	D	E	F
					
1PC	1PC	1PC	2 PCS	1PC	1PC
G	H	I	J	K	L
					
1PC	1PC	1PC	1PC	1PC	1PC
M	N	O	P	Q	R
					
1PC	1PC	1PC	1PC	1PC	1PC

HARDWARE:




①	②	③	④	⑤	⑥
					
1/4"x25mm	Ø4x25mm	Ø8x30mm	Ø6x30mm		12"x45mm
14+1 PCS	4 PCS	18+1 PCS	12+1 PCS	2 PCS	1 SET
⑦	⑧	⑨	⑩	⑪	⑫
					
Ø6x33mm	Ø15x9mm	5/32"x18mm	Ø3x10mm	Ø4x12mm	
18+1 PCS	18+1 PCS	2 PCS	12+1 PCS	12+1 PCS	2 PCS
⑬	⑭				
					
Ø3x12mm	20x20x33mm				
8 PCS	2 PCS				


STEP 1

- ③  8pcs
Ø8x30mm





STEP 2

- ③  2pcs
Ø8x30mm
- ⑬  4pcs
Ø3x12mm
- ⑭  2pcs
20x20x33mm





STEP 3

③  4pcs
Ø8x30mm





STEP 4

③  4pcs
Ø8x30mm




STEP 5

- ⑥  1SET
12"x45mm




STEP 6

- ⑥a  12"x45mm

- ⑩  3pcs
Ø3x10mm

- ⑦  3pcs
Ø6x33mm




STEP 7

6a 12"x45mm

10 Ø3x10mm 3pcs


7 Ø6x33mm 3pcs





STEP 8


1 1/4"x25mm 4pcs

13 Ø3x12mm 2pcs







STEP 9

- ①  3pcs 1/4"x25mm
- ⑧  3pcs Ø15x9mm






STEP 10



- ①  7pcs 1/4"x25mm
- ⑧  3pcs Ø15x9mm
- ⑬  2pcs Ø3x12mm




STEP 11




STEP 12




STEP 13




②  4pcs
Ø4x25mm




STEP 14







STEP 15


- ⑧  4pcs $\text{Ø}15 \times 9 \text{mm}$
⑨  1pc $5/32" \times 18 \text{mm}$
⑫  1pc





STEP 16




STEP 17


④  4pcs
Ø6x30mm

⑦  4pcs
Ø6x33mm





STEP 18

④  8pcs
Ø6x30mm







STEP 19

- ⑧  4pcs
Ø15x9mm





STEP 20

- ⑤  2pcs
⑦  4pcs
Ø6x33mm
⑪  4pcs
Ø4x12mm



STEP 21

⑧  4pcs
 Ø15x9mm






STEP 22



⑪  8pcs
 Ø4x12mm

Three-way adjustable hinge for perfectly aligned doors


1. TO ADJUST DOOR FORWARD OR BACKWARD.
2. TO ADJUST DOOR TO RIGHT OR TO LEFT.
3. TO ADJUST DOOR UP OR DOWN.




STEP 23



STEP 24



To install the Top (1) to the vanity (2). Apply silicone caulk to the top edge of the wood cabinet. With the help of another adult, gently lower the Sink top with assembled sink onto the cabinet. Make sure the Sink top is flush with the back side of the wood cabinet and the wood cabinet left and right side walls.



IMPORTANT-READ CAREFULLY-RETAIN FOR FUTURE REFERENCE

WARNING:

- Children must stay away from the assembly zone, preventing children from potential asphyxia because of plastic bag and foam breathing in nose;
- For your safety, please do not tread or climb product.
- The loading weight shall be within the range that vendor claims. The product is designed for adults use, domestic use and indoor use only.
- The product shall not combine with other product for use.
- If the product with seat height adjustments with energy accumulators that only trained personnel may replace or repair seat height adjustment components with energy accumulators
- Check regularly that all assembly fastenings are properly tightened, do not use the product if any structural part is broken or missing
- Incorrect installation and incorrect use can cause accidents. Please completely follow the guidance of assembly instruction.

Security instructions:

- Before assembling check whether all parts listed in the parts list have been delivered. Do not start assembling if parts are missing or damaged.
- A failure to assemble this product correctly could cause damage or result in serious injury! Before assembling make sure that you have enough space for the procedure. Assemble on a flat surface.
- Keep the assembly instructions available at all times and follow each of the individual steps exactly.
- During assembly, be careful with all the parts of the assembly (do not walk on them or distort them) and beware of shearing and trapping risks. Keep children and pets away while setting up the furniture.