


Instruction Manual




ITEM NO.HMGG0020

NOTE:

This brochure contains IMPORTANT safty info. Please read and keep for future reference.

MAINTAINANCE AND WARNING


- 1.Keep furniture away from heat sources.
- 2.Do not clean furniture with harsh cleaner or polishes.Do not use detergents,solvents,abrasives,spray packs or leather cleaner. Use non-color mild soa with warm water to clean spills(Mix 1:10 soap to water).
- 3.Do not place furniture under direct sunlight,material will possibly fade over time.
- 4.Do not use on site dry cleaning machine.Children should not climb or jump on the furniture.
- 5.Do not write on furniture that is not protectedby a padded barrier.
- 6.Not for commercial use,only for residential use.



Weight Limitation
















100 LBS

EXPLOSIVE VIEW













2 PERSONEN

PARTS LIST

A x1 	B x1 	C x1 	D x1 
E x1 	F x1 	G x4 	H x3 
I x1 	J x1 	K x3 	L x1 
M x2 	N x2 	O x2 	


HARDWARE LIST



1	x10+1	2	x10+1	3	x8	4	x16+1	5	x16+1	6	x16+1
											
				Φ8*30mm		Φ1/4"*1/2"		Φ1/4"		Φ1/4"	
7	x26+1	8	x2	9	x2	10	x14	11	x2	12	x1
											
Φ8#*1"											
13	x9	14	x9	15	x12	16	x2	17	x2	18	x1
											
		Φ4*25mm		Φ4*13mm				Φ3.5*35mm			
19	x1	20	x1								
											
M4											

ASSEMBLY INSTRUCTIONS

STEP-1

1.Attached the panel E to the top panel A and tighten the screws #7





7	x2	20	x1
			
Φ 8#*1"			


ASSEMBLY INSTRUCTIONS


STEP-2


- 1.Put the bolts #1 and wood dowel #3 into the side panel C
- 2.Attached the top panel A and panel E to the side panel C and tighten the cam #2



1	x3
	

2	x3
	


3	x2
	
Φ8*30mm	





20	x1
	

ASSEMBLY INSTRUCTIONS

STEP-3

- 1.Put the bolts #1 and wood dowel #3 into the side panel C
- 2.Attached the bottom panel B to the side panel C and tighten the cam #2








1	x2	2	x2	3	x2	20	x1
							
				Φ8*30mm			

ASSEMBLY INSTRUCTIONS

STEP-4


- 1.Put the bolts #1 and wood dowel #3 into the bottom panel B and front panel A&E
- 2.Attached the side panel D to the bottom panel B and front panel A&E, tighten the cam #2



ASSEMBLY INSTRUCTIONS

STEP-5

1.Attached the legs G to the bottom panel B, tighten the screws #4



4	x16
	
Φ1/4"*1/2"	

5	x16
	
Φ1/4"	


6	x16
	
Φ1/4"	




19	x1
	
M4	

ASSEMBLY INSTRUCTIONS

STEP-6

- 1.Attached the back panel F to the side panels C&D, tighten the screws #10
- 2.Attached the anti tipping #8 and tighten the screws #9






8	x1	9	x2	10	x14	20	x1
							
		Φ3.5*14mm		Φ3*14mm			

ASSEMBLY INSTRUCTIONS

STEP-7

1.Attached the electric board #12 to the top panel A and tighten the screws#11






11	x2	12	x1	20	x1
					
Φ 3*15mm					

ASSEMBLY INSTRUCTIONS

STEP-8

1. Attached the drawer left I and right J panels to the drawer front panel H and tighten the screws #7
2. Put the drawer bottom panel L to the groove of the drawer Left I and right J panel





7	x4	20	x1
			
Φ8#*1"			


ASSEMBLY INSTRUCTIONS

STEP-9


1. Attached the drawer back panel K to the drawer left I and right J panel , then tighten the screws #7
2. Attached the handle #13 to the drawer front panels



7	x4
	
Φ8#*1"	

13	x3
	


14	x3
	
Φ4*25mm	

20	x1
	

ASSEMBLY INSTRUCTIONS

STEP-10


1.Attached the drawers , make sure the sliders are aligned and tighten the screws #15





ASSEMBLY INSTRUCTIONS

STEP-11

1. Attached the drawer left M and right N panels to the drawer front panel H and tighten the screws #7
2. Put the drawer bottom panel O to the groove of the drawer Left M and right N panel





7	x8	20	x1
			
Φ 8#*1"			


ASSEMBLY INSTRUCTIONS

STEP-12


1. Attached the drawer back panel K to the drawer left M and right N panel , then tighten the screws #7
2. Attached the handle #13 to the drawer front panels



7	x8
	
Φ8#*1"	

13	x6
	


14	x6
	
Φ4*25mm	

20	x1
	

ASSEMBLY INSTRUCTIONS

STEP-13

1.Attached the drawers , make sure the sliders are aligned and tighten the screws #15





ASSEMBLY INSTRUCTIONS


STEP-14

Attach the unit to the wall with **plastic belt #18**


Anti-tipping hardware must be used for this product to avoid tipping and injury. If the unit is not stable, please adjust the adjustable level.







1. Drill a hole in the wall with an electric drill.



2. Tap the plastic wall anchor into the hole with a hammer.



3. Secure the Anti-tip device ⑧ to the wall with screws ⑰.



ASSEMBLY INSTRUCTIONS

STEP-15



WARNING

Children have died from furniture tipover.

To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- For use with televisions weighing 35 lb or less. Use with heavier televisions may result in instability causing tip-over resulting in death or serious injury.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

