

# ASSEMBLY INSTRUCTION

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which have come loose inside the carton during shipment. Identify and count all parts and compare with the part list below. Place all wooden furniture parts on a clean and flat soft surface, such as carpet or rug to prevent from being scratched.

| LIST OF PARTS |             |     |
|---------------|-------------|-----|
| No            | Description | Qty |
| 1             | Chair Back  | 2   |
| 2             | Front Legs  | 2   |
| 3             | Apron       | 4   |
| 4             | Chair Seat  | 2   |
| 5             | Stretcher   | 4   |

| LIST OF PARTS |               |     |
|---------------|---------------|-----|
| No            | Description   | Qty |
| A             | JCBC          | 12  |
| B             | Spring washer | 12  |
| C             | Wood Screw    | 14  |
| D             | Allen Key     | 1   |
| E             | Wood Dowel    | 12  |

**IMPORTANT!** Please ensure all bolts are inserted before tightening.

## WARNING

- This Chair not suitable for Standing On
- Do Not over Tighten the bolts and screw

