

USER'S MANUAL

Product Name:
Portable Umbrella With Stand



THIS INSTRUCTION BOOKLET CONTAINS
IMPORTANT SAFETY INFORMATION.
PLEASE READ AND KEEP FOR FUTURE REFERENCE.



SAFETY NOTES






- **IMPORTANT!** Always close or put down the umbrella when not in use. Do not use or assemble the umbrella in heavy winds, rain, thunderstorms, or snow. In such weather conditions, it is recommended to fold down or disassemble the umbrella.
 - **IMPORTANT!** Keep children and pets away while setting up the umbrella. Children must always be supervised around the umbrella.
To prevent damage, face the canopy against the wind.
 - **WARNING!** Do not light any fires under or near the umbrella!
This umbrella is for outdoor use only and is primarily intended to be used as a sunshade, not as wind protection.
This product has been tested for both domestic and commercial use.
-

CARE INSTRUCTIONS


- **Canopy Cleaning:** To clean the canopy fabric, use mild soap or warm water with a clean, dry cloth or a soft brush to remove spots. Never use solvent-based detergents, as these may bleach the material and damage the fabric. Do not use alkali or acidic detergents or steam cleaners.
- **Frame Cleaning:** To clean the umbrella frame, wipe it with a mild soap solution. It is not recommended to clean plastic or metal products with strong cleaners or abrasive materials, as they may discolor or damage the surface.
The umbrella frame is painted with a powder coating of plastic paint for protection. The frame will not be protected once the coating is damaged (e.g., rusting).
- **Frame Repair:** To repair a damaged frame, repaint it to restore its protective coating.

PARTS LIST


A x1	B x1	C x1
		
Upper Umbrella	Lower Umbrella Pole	Portable Umbrella Stand

D x1	F x3	G x1	H x1
			
Hook			
E x1			
			
Folding Cup Holder	L-shaped ground stakes	Umbrella Bag	Umbrella Stand Bag


INSTALL FOLDING CUP HOLDER



① Insert the longer end of the single-sided cup holder into the groove.



② Gently push inward until you hear a 'click' to confirm it's locked in place.





TO SET UP THE UMBRELLA

STEP 1

Press down to open the umbrella stand.
Turn the knob to secure the umbrella stand.


NOTE:

Be careful not to get your fingers caught in the gap.




STEP 2

Slide the the folding cup holder onto the Lower Umbrella Pole (B), then tighten the knob to secure it.




STEP 3

Insert the Lower Umbrella Pole (B) into the umbrella stand. Turn the knob to secure the umbrella stand.




STEP 4

Slide the hook onto the upper umbrella pole(A), then tighten the knob to secure it.



STEP 5


Insert the upper shaft, then tighten the knob to secure it.



STEP 6

When Used on Soft Ground, L-shaped ground stakes can be employed to further enhance the stability of the umbrella.

For Use on Hard Surfaces: If placing the umbrella on concrete or other hard surfaces, secure the base with a sandbag or similar heavy object to prevent tipping or blowing away.



STEP 7


Press the button to tilt the umbrella canopy
(both sides can be adjusted by an angle of 30° each).

If the button sticks after turning, gently lift the canopy up until you hear a click to reset it.

Reason: This usually happens if the ribs aren't fully open or if parts are new and tight. Lifting it relieves pressure and lets the spring inside snap back.

Tip: Always check that all ribs are fully extended first. If lifting doesn't work, please contact support.

BUTTON



THANK YOU FOR SHOPPING WITH US!

WARRANTY INFORMATION

- We offer a limited number of free extended 1-year warranties, including VIP customer service privileges. To activate, within 7 days of receiving your order.
- From the activation date, we offer a no-questions-asked warranty against defects in materials and workmanship. During this period, we will repair or replace any defective component at our discretion.
- This warranty is limited to manufacturing defects associated with the products and does not cover any damage caused by improperly installed handled or abused by user, nor to any unit which has been repaired or altered by unauthorized repair companies.
- Under no circumstances will the customer be entitled to warranty consequential or incidental damages. This limited 1-year warranty will only grant customers certain legal rights; Customers may have other rights according to different state laws.

CUSTOMER SERVICE

If you have any questions or need assistance, feel free to contact our brand's official customer service anytime

To help us locate your order, please include your Order Number. Our 24-hour customer service team will be happy to assist you, and we typically respond within hours.

Customer Service Team