

IMPORTANT INSTRUCTIONS DO NOT DESTROY

Thank you for purchasing

TABLE OF CONTENTS

SET UP PROCEDURES.....1	CARE AND CLEANING.....4
CONTROLLER FEATURES.....2	TROUBLESHOOTING.....5
SAFETY ESSENTIALS.....3	

SET UP PROCEDURES

STEP 1

Place controllers near the head of the bed. Queen and King blankets include two controllers that operate independently. Cord should run from the controller under bed connecting to the end of the blanket at the foot of the bed.

STEP 2

Connect Power Cord Connect power cord to the blanket by matching the arrow on the power cord to the arrow on the connector. Once arrows are aligned, push cord into the connector until they are securely connected. You should feel it snap into position.




STEP 3

Plug Controller into the wall Once you have properly attached power cord to the connector, plug your heated blanket into the wall. Queen and King Sizes will have two power cords.

CAUTION:

- Do not plug main power cord into the wall outlet until you have completely set up your heated product per the instructions.
- Disconnected power cord from the wall before detaching controller cord from your heated product.
- Always make sure cords are not pinched between mattress, bed slats, furniture, wall, or any surface.
- This product has a polarized plug(one plug blade is wider than the other). To reduce the risk of electrical shock, if this plug does not fit in the outlet, reverse the plug. If it still does not fit, contact an electrician. Do not attempt to defeat this safety feature.



CONTROLLER FEATURES

DUAL CONTROLLERS All queen and king sizes have two controllers. Power On/Off, Temperature setting and auto-shut off features for each controller with the same button .

AUTO SHUT OFF FEATURE Each controller will automatically shut off 10 hours after the controller is turned on. This is designed to provide added safety and conserve energy. To reactivate the heating feature simply press the button. To restart after a power outage simply press the button.



1. To turn on the controller, press the Power button in center of controller. LCD will display the blanket model code for 2 seconds (b1, b2, or b3), then will light up and display "L" which is the default setting. Default time is 10 hours and blanket will automatically shut off then.
 2. Press Temp +/-, LCD will display temperature setting from Low through High.
 3. Press Timer +/-, LCD will display the auto off function with the adjustable time setting from 0.5 to 12 hours.
 4. Allow 30 minutes for blanket to fully preheat.
- CAUTION: ALWAYS turn the heated blanket "OFF" when not in use.

SAFETY ESSENTIALS

Setting up

- Never trap or pinch any of the electrical cords in any way. Make sure the cords are never rested between the mattress and box springs.
- The heated area of the warming blanket should always lie flat on top of the mattress to prevent overheating.
- If the plug does not fit into your outlet, contact a qualified electrician.
- Be sure that the power supply is used only on 120V, 60HZ Current Supply.
- Make sure the cord from the controller to your heated product is connected and locked tightly.
- NEVER use your blanket with an airbed, a pull-out sofa or mechanically adjusted bed.
- You may use this electric blanket with any sheets, mattress pads or other blankets but never in combination with any other electric blankets.

- The warming products should never be folded, balled up or bunched in any way when in use. May result in overheating and/or permanent wrinkling of the fabric.
- Do not use with generators, power converters, or inverters.

Care and Maintenance

- Be sure to read carefully the accompanying instruction booklet before using this bedding .
- Do not tuck in the wired area of this bedding.
- Never use pins in and around the warming product – They may damage the electric wiring.
- Cats, dogs and other pets should always be kept away from the product, as a sharp claw may result in damage to the heating element.
- Keep the controls always from drafty areas that may become damp or wet, such as an open window.

SAFETY ESSENTIALS

- Always turn off the electric current when the warming product is not in use, either by turn off the controller or unplugging from the wall outlet.
- Wrapping of the cord around the controls may damage the cord. Loop loosely when storing.
- NEVER iron your warming product.
- NEVER use dry cleaning fluid on this product. Cleaning solvents may damage the wiring insulation.
- If improper operation of this bedding is observed, discontinue its use immediately and consult the manufacturer or the dealer regarding its repair.
- Do not tuck the blanket or supply cord in a sofa or other furniture. All portions of the blanket or controller should be visible at all times.
- Wrapping of cord around the controller may damage the cord. Loop loosely when storing.
- Do not route electrical cords between the mattress and box spring. Do not allow the cords to be pinched.
- Do not use with rocking chairs, recliners, chair with casters or wheels or other furniture subject to movement.

CARE INSTRUCTIONS

To operate this warming product properly and safely, there are some critical safety precautions you need to follow. As with all electrical appliances, there is an inherent danger of overheating, fire or personal injury if the product is not used correctly. Please carefully read what follows before using the warming product.

Never use this warming product with:

- Infants or very small children;
- People with disabilities;
- Anyone who is immobile or cannot operate the controls properly;
- Anyone who is insensitive to heat (e.g. a person with poor circulation);
- Anyone who cannot or will not understand these directions.

WASHING INSTRUCTIONS

NEVER DRY CLEAN OR USE BLEACH. BEFORE WASHING, DISCONNECT ALL CORDS.

Do not dry-clean this bedding. Cleaning solvents may have a deteriorating effect on the insulation of the heating element.

MACHINE WASHING

NEVER submerge cords or control unit. Place textile portion without cords in the washing machine. Machine wash warm on gentle or delicate cycle.

HAND WASHING

Washing your warming product by hand is the best way to make it last. To do this, disconnect all cord(s). Wash your textile separately by hand in a tub of lukewarm(100°F) water using a small amount of mild laundry soap or detergent. Soak for 5 minutes. Next, gently work the textile up and down for five more minutes. NEVER rub or scrub. Rinse thoroughly in cool water until all traces of soap or detergent are gone. Squeeze excess water out by hand, NEVER twist. Do not use a wringer.

IMPORTANT INSTRUCTIONS

DRYING INSTRUCTIONS

NEVER USE COMMERCIAL DRYERS AT THE LAUNDROMAT-- THEY MAY BE EXTRA HOT AND COULD DAMAGE THE WIRING. DO NOT IRON. DO NOT PLUG IN UNTIL COMPLETELY DRY.

MACHINE DRY

To machine dry, put your product into a family washing machine and dryer on low heat below 40°C. Ensure that the textile has enough room to tumble freely. If blanket draws in during washing, while still damp gently stretch until it returns to its original size.

LINE DRY

You can line dry, simply by draping the warming blanket over two parallel clotheslines or a shower rod with the head and foot ends down. Do not reconnect warming products until they are completely dry. Do not use clothes pins that can pinch wires.

STORAGE

Store as you would any other bedding, folded in a dry place.

Q: The light on my controller does not light up.

A: Assure that all the wire connections are tight and that the power cord is connected to an “energized” socket (try a lamp to verify that the outlet is working properly)

Q: The controller is lit but the blanket does not heat up.

A: Test the product by folding the textile over on itself and turning on the controller. Ensure that controller lamp is lit. After approximately five minutes, carefully feel between the layers. Never leave the product turned on and folded up for more than a few minutes.

Q: I feel some warmth but not a lot. How warm should this blanket get?

A: This blanket will provide enough warmth to keep you quite comfortable even in an extremely cold room with only a light blanket on top. You should spend several nights experimenting with the heat settings until you find your personal comfort level. This blanket is not like a heating pad (this amount of heat would be too hot to use all night long). In normal operation, warming blankets do not feel hot to the touch.

IMPORTANT INSTRUCTIONS

Q: Can I sit or lie on my electric blanket?

A: Just sitting or lying on the blanket will not harm it. Jumping on it or other similar abuse may damage it.

Q: Can I use bedspread or comforter over my electric blanket?

A: You normally will not need more warmth than this blanket will provide. However, you make use any bedding you wish with this blanket except an Electric mattress pad, another electric blanket or a heating pad (overheating may occur).

Q: My blanket works fine but then seems to shut off.

A: The 10 hour automatic shutoff feature may have activated. Simply push the button again and your blanket will heat for an additional ten hours or until you turn it off. If ten hours have not elapsed, check that all your connections are tight and the wall outlet is not turn off.

Q: My power supply cord sparked at the wall outlet when I plugged it in.

A: Yes, many electric appliances will sometimes “snap” due to the inrush of electricity when first plugged in. This is completely normal and nothing to be concerned about it.

Q: Why is my controller warm?

A: A small amount of heat is produced when transferring power from the wall to the blanket. This warmth is completely normal and is nothing to be concerned about.