



Double-Sided Plexiglass Painting Board

ASSEMBLY INSTRUCTIONS


ITEM #RSAE-1021


Retain the instructions for future ref.


HARDWARE

A.Phillips screws
Long×3PCS **Short**×2PCS
 3.5*30mm  3.5*16mm





B.Plastic Anchor×4PCS
 6*30mm

C.Lockingbolt×8PCS
Have been pre-installed on parts.
 6*40mm

D.Hooks Set ×2PCS


E.Small Screw×6PCS


PARTS LIST





4 × 2

5




6 × 2

7


*Floor Mounting



Put part 7 into grooves between 2 parts 6.



Easy to hang up and take down.



Short Screw

Short Screw

Cup Holder

Put nut pieces into hole first!

Nut Piece hole

Attention:
Use two **short** screws to fix the frame from both sides as shown in the figure below.




Double-Sided Plexiglass Painting Board

ASSEMBLY INSTRUCTIONS

ITEM #RSAE-1021


Retain the instructions for future ref.

*For Wall Mounting




For safety reasons, we recommend that you install the Optional hooks!!!

Make 2 Punching Points For Hiden Hooks On Wall





Hang On The Board



Fixing Two Optional hooks

Anchor&Screw Installation



CAUTION:

Please determine the hanging height based on the kid's height. We recommend that the lowest of the drawing board be at least 10cm above the ground.

Reminder: If you have any issues with the product please e-mail us for support at **scg4586@yeah.net.**

IMPORTANT INFORMATION-PLEASE READ FIRST:

ALL OF OUR WOODEN ITEMS ARE HANDCRAFTED, HAND ASSEMBLED, AND HAND PAINTED. EACH ONE IS UNIQUE. SLIGHT IMPERFECTIONS MAY OCCUR AND ARE NOT MANUFACTURING DEFECTS. EACH ITEM HAS BEEN PAINTED WITH VERY DURABLE PAINT THAT IS BOTH LEAD AND CHROMATE FREE AND SAFE FOR CHILDREN. HOWEVER, IT WILL NOT WITHSTAND ABNORMAL ABUSE AND WITH IMPROPER USE, IT COULD CHIP. PLEASE NOTE THAT WE DO NOT WARRANTY AGAINST THE USE OF PERMANENT MARKERS, NON-WATER-BASED PAINTS, CRAYONS, OR WASHABLE MARKERS. SOME OF THESE ITEMS CONTAIN PERMANENT COLOR DYES THAT COULD DAMAGE THE SURFACE.

WARRANTY

IMPORTANT: EVIDENCE OF ORIGINAL PURCHASE IS REQUIRED FOR WARRANTY SERVICE.

LENGTH OF WARRANTY: 90 DAYS FROM DATE OF PURCHASE.

THIS WARRANTY COVERS DEFECTS THAT WERE A RESULT OF THE MANUFACTURER'S PRODUCTIONS. YOU SHOULD CAREFULLY INSPECT THE CONDITION OF THE PRODUCT PRIOR TO ASSEMBLY. THIS WARRANTY IS INVALID IF THE PRODUCT IS DAMAGED OR NOT MAINTAINED PROPERLY.

Development zone of Heilin Ganyu section Lianyungang Jiangsu Prov. China.
Powered by Lianyungang Yubao I/E CO., LTD
Kids Furniture Research And Development
www.krand.com.cn
K R A N D

! WARNING:

Choking Hazard : Small parts
Not for children under 2 years and put it to somewhere children can't reach.

CAUTION:

Adult assembly required.
Hardware contains small screws with sharp points. Keep unassembled parts.

MAINTENANCE:

-Placing on flat and level surface while using.
-Ensure the product continues to function properly and safely by regularly checking the hardware and tightening when necessary.