

Assembly Instructions				
Caution: You must read this before you proceed				
Trolley				
Parts List				
Label	Picture	Description	QTY	
A		Front Panel	1	
В		Back Panel With Legs	1	
С		Bottom Basket	1	
D		Top Shelf Frame (with preassembled Glass suction cups)	1	
E		Glass	1	
F		Wheel	2	
G	A A A A A A A A A A A A A A A A A A A	Wine Glass Rack	1	
Н		Ice Bucket	1	

Hardware				
Label	Picture	Description	QTY	
I		Wrench	1	
J		Spring Washer	3	
К		Washer(Small)	13	
L		Bolt (M6*45mm)	13	
М		Allen Wrench	1	
N		Allen Wrench (With Cross Screwdriver)	1	
0		Bolt (M5*20mm)	7	
Р		Washer(Big)	3	
Assembly Preparation				
Betore Be	eginning Assembly:			
<ul> <li>Read instructions, cover to cover-</li> <li>Have 2 adults on hand for assembly-</li> <li>Do not assemble on flooring or carpet-</li> <li>Assemble on a clean non-marring surface (packing foam)-</li> <li>Save all packaging until finished-</li> </ul>				

## Assembly Steps





Place the Top Shelf Frame(D) face down.

Attach Wine Glass Rack(G) to Top Shelf Frame(D) using Bolts(O) with Allen Wrench(N).

Fully and Securely tighten the Bolts of the Glass Rack to the Shelf Frame.

## Step 4




Attach Top Shelf Frame(D) between Back Panel With Legs(B) and Front Panel(A) using Washers(K) and Bolts(L) with Allen Wrench(M) as pictured above. **Note: Please keep Wine Glass Rack(G) at the same end with the Front Panel(A).** 

Test for levelness.

Now in a sequential manner, proceed to tighten all Bolts at all joints.

Note: DO NOT fully tighten a BOLT in one go and then move on to the next. Rather, in a sequential manner, gradually tighten each Bolt until all Bolts are evenly secured. This methodology will ensure maximum evenness once all Bolts are fully tightened.



Care & Maintenance			
0 <u></u> •	Do not put hot items directly on furniture surface		
\[         \]     \[	Do not clean furniture with harsh cleansers or polish.		
~ Ö •	To obtain the longest lifespan of your outdoor prodcts, minimizing exposure to direct sunlight is recommended.		
◎ 🟋 •	Children should not climb or jump on the furniture.		
	Do not write on furniture without a padded barrier to protect the surface.		
~ <u></u>	To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.		
	Not for commercial use. For residential use only .		
• •	Stains may be removed with mild soap solution and damp cloth.		
<ul> <li></li></ul>	Keep away from sources of ignition.		
✓ <b>○</b> •	Dust and pick-up spills using a clean, non-colored, lint-free cloth .		