



QUICK START GUIDE

- | | |
|---------------------------------------|-----------------------------------|
| A PREVIOUS TRACK / VOLUME DOWN | E TIME SETTING MODE |
| B NEXT TRACK / VOLUME UP | F TIME ADJUST |
| C PLAY / PAUSE / CALL | G MICRO-USB CHARGING INPUT |
| D BLUETOOTH MODE | H DIGITAL DISPLAY |

CHARGING YOUR MELODY DUOTONE MAKEUP MIRROR + BLUETOOTH SPEAKER

Connect the included cable to the **G** Micro-USB charging input then plug the other end into a standard USB charging outlet. The **USB** indicator will appear and the **BATTERY** icon will start blinking on the display to indicate charging. The battery symbol will stop blinking once the battery is fully charged.

For best results, keep your Melody plugged in to a charger during continuous extended use.

USING YOUR MELODY'S DIMMABLE DUOTONE LIGHTING

Turn the lighting on and off with a simple tap of the upper soft-touch sensor button on the mirror. To adjust the brightness, press and hold the upper button down until your perfect intensity is reached. Use the lower soft-touch sensor button to gradually adjust the LED color temperature from cool daylight into a warm soft white tone.

BLUETOOTH MODE

- BT ON / OFF:** press and hold **D** **BLUETOOTH** until the **BLUETOOTH ON / OFF** indicator appears on the display
- BT PAIRING MODE:** press and hold **D** **BLUETOOTH** until you hear a prompt and the **BLUETOOTH** icon starts blinking

CONNECTING YOUR BLUETOOTH DEVICE FOR THE FIRST TIME

Press and hold **D** until you hear the Bluetooth mode prompt and the Bluetooth symbol starts blinking on the display. Connect to the Melody on your device's Bluetooth menu. The Bluetooth symbol will stop blinking once connected. After initial pairing, Melody will automatically connect to your device when Bluetooth mode is turned on within range. Melody's Bluetooth mode will automatically turn off if no device is connected after a few minutes or whenever the battery is running low to preserve power.

CONNECTING A DIFFERENT BLUETOOTH DEVICE

Disconnect your connected Bluetooth device from the Melody to turn standby mode on, and then press and hold **D** to activate pairing mode and connect a new device.

AUDIO PLAYBACK & SPEAKERPHONE CONTROLS

- | | | | |
|------------------------|---|---------------------|---|
| PREVIOUS TRACK: | press A to play the previous track | VOLUME DOWN: | press and hold A |
| NEXT TRACK: | press B to skip to the next track | VOLUME UP: | press and hold B |
| PLAY AUDIO: | press C to start playing audio | ANSWER CALL: | press C to answer an incoming call |
| PAUSE AUDIO: | press C during playback to pause audio | END CALL: | press C during phone call |

SETTING THE DIGITAL CLOCK

Press and hold **E** until you the minute indicator starts blinking on the digital display. Press **F** to advance the time and repeat until the correct number is reached. Press **E** to switch to the hour setting mode. Once done, press **D** set the clock or wait for the time setting mode to automatically expire after 30 seconds of inactivity.

NOTES AND PRECAUTIONS

- Please fully charge your Melody before first use to help ensure optimum battery performance and lifespan.
- Unplug the device if left unused for extended periods or during storage. Recharge periodically to preserve battery life.
- Due to the difference in power requirements, it is normal for the LED lighting to function several minutes before the Bluetooth speaker when charging from a completely drained battery.



QUICK START GUIDE

- A

PREVIOUS TRACK / VOLUME DOWN
- B

NEXT TRACK / VOLUME UP
- C

PLAY / PAUSE / CALL
- D

BLUETOOTH MODE
- E

TIME SETTING MODE
- F

TIME ADJUST
- G

MICRO-USB CHARGING INPUT
- H

DIGITAL DISPLAY

CHARGING YOUR MELODY DUOTONE MAKEUP MIRROR + BLUETOOTH SPEAKER

Connect the included cable to the **G** Micro-USB charging input then plug the other end into a standard USB charging outlet. The **USB** indicator will appear and the **BATTERY** icon will start blinking on the display to indicate charging. The battery symbol will stop blinking once the battery is fully charged.

For best results, keep your Melody plugged in to a charger during continuous extended use.

USING YOUR MELODY'S DIMMABLE DUOTONE LIGHTING

Turn the lighting on and off with a simple tap of the upper soft-touch sensor button on the mirror. To adjust the brightness, press and hold the upper button down until your perfect intensity is reached. Use the lower soft-touch sensor button to gradually adjust the LED color temperature from cool daylight into a warm soft white tone.

BLUETOOTH MODE

BT ON / OFF: press and hold **D** **BLUETOOTH** until the **BLUETOOTH ON / OFF** indicator appears on the display
BT PAIRING MODE: press and hold **D** **BLUETOOTH** until you hear a prompt and the **BLUETOOTH** icon starts blinking

CONNECTING YOUR BLUETOOTH DEVICE FOR THE FIRST TIME

Press and hold **D** until you hear the Bluetooth mode prompt and the Bluetooth symbol starts blinking on the display. Connect to the Melody on your device's Bluetooth menu. The Bluetooth symbol will stop blinking once connected. After initial pairing, Melody will automatically connect to your device when Bluetooth mode is turned on within range.

Melody's Bluetooth mode will automatically turn off if no device is connected after a few minutes or whenever the battery is running low to preserve power.

CONNECTING A DIFFERENT BLUETOOTH DEVICE

Disconnect your connected Bluetooth device from the Melody to turn standby mode on, and then press and hold **D** to activate pairing mode and connect a new device.

AUDIO PLAYBACK & SPEAKERPHONE CONTROLS

PREVIOUS TRACK:	press A to play the previous track	VOLUME DOWN:	press and hold A
NEXT TRACK:	press B to skip to the next track	VOLUME UP:	press and hold B
PLAY AUDIO:	press C to start playing audio	ANSWER CALL:	press C to answer an incoming call
PAUSE AUDIO:	press C during playback to pause audio	END CALL:	press C during phone call

SETTING THE DIGITAL CLOCK

Press and hold **F** until you the minute indicator starts blinking on the digital display. Press **F** to advance the time and repeat until the correct number is reached. Press **F** to switch to the hour setting mode. Once done, press **D** set the clock or wait for the time setting mode to automatically expire after 30 seconds of inactivity.

NOTES AND PRECAUTIONS

Please fully charge your Melody before first use to help ensure optimum battery performance and lifespan.
Unplug the device if left unused for extended periods or during storage. Recharge periodically to preserve battery life.
Due to the difference in power requirements, it is normal for the LED lighting to function several minutes before the Bluetooth speaker when charging from a completely drained battery.



QUICK START GUIDE

- | | |
|---------------------------------------|-----------------------------------|
| A PREVIOUS TRACK / VOLUME DOWN | E TIME SETTING MODE |
| B NEXT TRACK / VOLUME UP | F TIME ADJUST |
| C PLAY / PAUSE / CALL | G MICRO-USB CHARGING INPUT |
| D BLUETOOTH MODE | H DIGITAL DISPLAY |

CHARGING YOUR MELODY DUOTONE MAKEUP MIRROR + BLUETOOTH SPEAKER

Connect the included cable to the **G** Micro-USB charging input then plug the other end into a standard USB charging outlet. The **USB** indicator will appear and the **BATTERY** icon will start blinking on the display to indicate charging. The battery symbol will stop blinking once the battery is fully charged.

For best results, keep your Melody plugged in to a charger during continuous extended use.

USING YOUR MELODY'S DIMMABLE DUOTONE LIGHTING

Turn the lighting on and off with a simple tap of the upper soft-touch sensor button on the mirror. To adjust the brightness, press and hold the upper button down until your perfect intensity is reached. Use the lower soft-touch sensor button to gradually adjust the LED color temperature from cool daylight into a warm soft white tone.

BLUETOOTH MODE

- BT ON / OFF:** press and hold **D** **BLUETOOTH** until the **BLUETOOTH ON / OFF** indicator appears on the display
- BT PAIRING MODE:** press and hold **D** **BLUETOOTH** until you hear a prompt and the **BLUETOOTH** icon starts blinking

CONNECTING YOUR BLUETOOTH DEVICE FOR THE FIRST TIME

Press and hold **D** until you hear the Bluetooth mode prompt and the Bluetooth symbol starts blinking on the display. Connect to the Melody on your device's Bluetooth menu. The Bluetooth symbol will stop blinking once connected. After initial pairing, Melody will automatically connect to your device when Bluetooth mode is turned on within range. Melody's Bluetooth mode will automatically turn off if no device is connected after a few minutes or whenever the battery is running low to preserve power.

CONNECTING A DIFFERENT BLUETOOTH DEVICE

Disconnect your connected Bluetooth device from the Melody to turn standby mode on, and then press and hold **D** to activate pairing mode and connect a new device.

AUDIO PLAYBACK & SPEAKERPHONE CONTROLS

- | | | | |
|------------------------|---|---------------------|---|
| PREVIOUS TRACK: | press A to play the previous track | VOLUME DOWN: | press and hold A |
| NEXT TRACK: | press B to skip to the next track | VOLUME UP: | press and hold B |
| PLAY AUDIO: | press C to start playing audio | ANSWER CALL: | press C to answer an incoming call |
| PAUSE AUDIO: | press C during playback to pause audio | END CALL: | press C during phone call |

SETTING THE DIGITAL CLOCK

Press and hold **E** until you the minute indicator starts blinking on the digital display. Press **F** to advance the time and repeat until the correct number is reached. Press **F** to switch to the hour setting mode. Once done, press **D** set the clock or wait for the time setting mode to automatically expire after 30 seconds of inactivity.

NOTES AND PRECAUTIONS

- Please fully charge your Melody before first use to help ensure optimum battery performance and lifespan.
- Unplug the device if left unused for extended periods or during storage. Recharge periodically to preserve battery life.
- Due to the difference in power requirements, it is normal for the LED lighting to function several minutes before the Bluetooth speaker when charging from a completely drained battery.



QUICK START GUIDE

- A

PREVIOUS TRACK / VOLUME DOWN
- B

NEXT TRACK / VOLUME UP
- C

PLAY / PAUSE / CALL
- D

BLUETOOTH MODE
- E

TIME SETTING MODE
- F

TIME ADJUST
- G

MICRO-USB CHARGING INPUT
- H

DIGITAL DISPLAY

CHARGING YOUR MELODY DUOTONE MAKEUP MIRROR + BLUETOOTH SPEAKER

Connect the included cable to the **G** Micro-USB charging input then plug the other end into a standard USB charging outlet. The **USB** indicator will appear and the **BATTERY** icon will start blinking on the display to indicate charging. The battery symbol will stop blinking once the battery is fully charged. For best results, keep your Melody plugged in to a charger during continuous extended use.

USING YOUR MELODY'S DIMMABLE DUOTONE LIGHTING

Turn the lighting on and off with a simple tap of the upper soft-touch sensor button on the mirror. To adjust the brightness, press and hold the upper button down until your perfect intensity is reached. Use the lower soft-touch sensor button to gradually adjust the LED color temperature from cool daylight into a warm soft white tone.

BLUETOOTH MODE

- BT ON / OFF:

press and hold **D** **BLUETOOTH** until the **BLUETOOTH ON / OFF** indicator appears on the display
- BT PAIRING MODE:

press and hold **D** **BLUETOOTH** until you hear a prompt and the **BLUETOOTH** icon starts blinking

CONNECTING YOUR BLUETOOTH DEVICE FOR THE FIRST TIME

Press and hold **D** until you hear the Bluetooth mode prompt and the Bluetooth symbol starts blinking on the display. Connect to the Melody on your device's Bluetooth menu. The Bluetooth symbol will stop blinking once connected. After initial pairing, Melody will automatically connect to your device when Bluetooth mode is turned on within range. Melody's Bluetooth mode will automatically turn off if no device is connected after a few minutes or whenever the battery is running low to preserve power.

CONNECTING A DIFFERENT BLUETOOTH DEVICE

Disconnect your connected Bluetooth device from the Melody to turn standby mode on, and then press and hold **D** to activate pairing mode and connect a new device.

AUDIO PLAYBACK & SPEAKERPHONE CONTROLS

- PREVIOUS TRACK:

press **A** to play the previous track
- NEXT TRACK:

press **B** to skip to the next track
- PLAY AUDIO:

press **C** to start playing audio
- PAUSE AUDIO:

press **C** during playback to pause audio
- VOLUME DOWN:

press and hold **A**
- VOLUME UP:

press and hold **B**
- ANSWER CALL:

press **C** to answer an incoming call
- END CALL:

press **C** during phone call

SETTING THE DIGITAL CLOCK

Press and hold **E** until you the minute indicator starts blinking on the digital display. Press **F** to advance the time and repeat until the correct number is reached. Press **F** to switch to the hour setting mode. Once done, press **D** set the clock or wait for the time setting mode to automatically expire after 30 seconds of inactivity.

NOTES AND PRECAUTIONS

- Please fully charge your Melody before first use to help ensure optimum battery performance and lifespan.
- Unplug the device if left unused for extended periods or during storage. Recharge periodically to preserve battery life.
- Due to the difference in power requirements, it is normal for the LED lighting to function several minutes before the Bluetooth speaker when charging from a completely drained battery.