


Assembly Instructions & Care Guide

Illustrations in this guide are for reference only and may differ slightly from the actual product

CONTENT

Before You Start

Overview
Caution
Material Specifications

Installation Guide

Exploded Views 01
Component Parts 02
Hardware 02
Assembly Directions 03-07
Troubleshoot 08

Usage and Maintenance

Door Panel Adjustment Instruction 09-10
Use and Care 11

Other

Help Center 12

Before You Start

Overview

1. Check and ensure you have received all packages and necessary parts.
2. Prepare adequate assembly space. We recommend using pads or cardboard to prevent the floor from scratches.
3. Read the instructions to familiarize yourself with the assembly requirements. Allow sufficient time and have someone available to assist you if needed.
4. Place all hardware on a soft surface for easy identification.
5. The seller is not responsible for any damage or injury caused by improper assembly or use.
6. If you need further assistance, please contact us

Caution

1. Children must not assemble this product. During assembly, keep small parts away from children as swallowing or inhaling them could be fatal.
2. Do not allow children to stand, climb, or play on the product, as it may tip over and cause serious injury.
3. Keep plastic packaging bags away from children to prevent risks of suffocation.
4. Avoid sharp objects and corrosive chemicals to prevent product damage or personal injury

Material Specifications

Solid Wood


Natural grains, scars, and color variations are inherent in real wood, which contribute to its unique beauty. Slight color changes may occur under different lighting and angles, due to variations in wood grain and light intensity.

Marble and Engineered Stone


Each marble and engineered stone piece has a unique pattern. Due to the nature of the materials, the pattern may differ from the one you see when purchasing.

Installation Guide


Exploded Views




Installation Guide



Ⓐ X1



Ⓑ X2



Ⓒ X1


Hardware

① X20




Ø5/16" Spring Washer

② X20




Φ5/16" Flat Washer

③ X4




Φ5/16x1-7/8" Bolt

④ X16




Φ5/16x1" Bolt

⑤ X1




Φ5/16x1-9/16" Bolt

⑥ X2




10"

⑦ X4




1"

⑧ X2



#5*25/32"

⑨ X2




#5*1-1/2"


Install your new product with care, following the instructions step-by-step. Do not skip any steps. Care-fully distinguish between left and right components. Do not over-tighten screws , as this may damage the product.

Tools You May Need

*You might need a screwdriver (+/-) to complete this assembly.



Persons and Time Needed For Assembly



Assembly Directions


STEP 1

⑤X1 Φ5/16x1-9/16" Bolt

③X4 Φ5/16x1-7/8" Bolt

①X4 Φ5/16" Spring Washer

②X4 Φ5/16" Flat Washer



Assembly Directions


STEP 2

① X16 Φ5/16" Spring Washer

② X16 Φ5/16" Flat Washer


④ X16 Φ5/16x1" Bolt

⑤ X1 Φ5/16x1-9/16" Bolt




Assembly Directions


STEP 3





Assembly Directions


STEP 4

⑥ X2  10"

⑦ X4  1"

⑧ X2  #5*25/32"

⑨ X2  #5*1-1/2"



Assembly Directions

STEP 5

SAFETY WALL STRAP INSTALLATION


Note: It is highly recommended to install this safety strap kit to prevent tipping,damage and/or injury.


1.Insert short screw (C) through Double hole iron sheet(B) and safety wall strap (E) and attach to top panel (part A)using philps head screwdriver.

2.Drll a 11/32" hole where you want to secure the unit. The drilled hole wil be at the same height as the hole intop panel (part A) where the safety wall strap (E) is attached.Tap wall anchor (A) into the hole.

3.Insert long screw (D) through Double hole iron sheet (B) and safety wall strap (E) into wall anchor (A) using philipshead screwdriver.

Note: This item is not intended for clothing storage use.





Finished!

Fantastic, we're nearly there! Please carry out the following checks:


1. Have you tightened all the screws?
2. Are the levelers aligned with and making contact with the ground?
3. Have you installed the anti-tipping kit?

Troubleshoot


Wood furniture	Door opening is not flexible	The furniture is not leveled	Use items to level the furniture
		The door hinges should be adjusted properly.	Adjust door hinges and apply lubricating oil.
	Inflexible opening of drawer	Overload or deformation	Reduce weight,adjust guide rails, lubricate
	Loose component connection	Loose hinges or screws	The poke part should be coated with an appropriate amount of 502 glue, then re-install or tighten the screws.
	Minor scratches	friction with hard o sharp objects	Use a brush to apply similar pigment ink along wood grain to the scratches, then wipe off the excess.
	Corrosive stains	Accidentally stained with chemical solvents such as nail polish, nail polish remover, ect.	Wipe them with a dry cotton cloth immediately

Possible Issues During Assembly:

- The two boards can't be aligned at he same level.




- Holes on the bards and poles are not aligned, so screws can't be installed.




Recommended Solution:

- Please sightly loosen all screws and adjust the bards. Because the diameter of the holes on the pipes 23 mm lager than that of bots, the position of the boards can be adjusted.



- If it is still doesn't work after adjustment, please contact us for more solutions.


Door Panel Adjustment Instruction



Front-to-Back Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved front-back.


Adjustment range: 4mm



Left-Right Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved left-right.

Adjustment range: 3mm




Up-Down Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved up-down.

Adjustment range: 4mm


Door Panel Adjustment Instruction


Common Door Panel Issues:



Door panel is not straight

Adjust the door hinges







The gap between door panels is too large

Adjust the door hinges


Finished







The door panels are not coplanar

Adjust the door hinges




Finished






The two door panels are not at the same height

Adjust the door hinges



Finished



Usage and Maintenance

Use and Care

- Leave it vacant for half a month before use, maintain good ventilation to eliminate any odor.
- Place items steadily, heavier items should be placed at the bottom to avoid tipping over. For high temperature or frozen items, please put a heat-resistant pad underneath.
- Do not directly push or drag hard objects on the furniture to avoid scratching the surface.
- Avoid prolonged exposure to sunlight or heat sources to prevent discoloration or fading.
- Pay attention to moisture prevention to avoid mold. Keep the furniture placed steadily to prevent breakage or loosening.
- Please educate children to stay away from the glass sharp corners of the furniture.
- When opening and closing doors or drawers, handle them gently and check the screws regularly to tighten them.
- Use a soft dry cloth to dust, a slightly damp cloth to clean the surface, avoid abrasive cleaners.

Help Center

Treat your furniture with care and follow the maintenance guidelines. In return, your furniture will provide you with lasting comfort and support. For any additional inquiries or assistance, please do not hesitate to contact us


Inquiry


Assembly issue


Missing parts


Returns&Refunds

We look forward to seeing you again soon.