


WIDE LADDER SHELF





**FOR REPLACEMENT PARTS OR HELP WITH
ASSEMBLY PLEASE CONTACT US**

**PLEASE ENSURE TO HAVE THE MODEL #
FROM THE PACKAGING OR INSTRUCTION BOOKLET**

**TO RETURN THE PRODUCT:
PLEASE CONTACT THE RETAILER
WHERE THE ITEM WAS PURCHASED FROM**

IMPORTANT : Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

SAFETY INFORMATION

Identify all the parts and hardware. Do not discard of the packaging until you have checked that you have all of the parts and hardware required.
Hardware package may have spare parts.

WARNING: This item contains small parts which can be swallowed by children and pets. Keep children and pets away during assembly. To avoid danger of suffocation, always keep plastic bags away from children and pets. We recommend that you assemble this unit on a carpeted floor to avoid scratches. If using power tools, set the tool to low torque to avoid damage.

May require 2 people for ease of assembly.


CARE and MAINTENANCE

To clean, use a soft or slightly damp cloth, then wipe with a clean, dry cloth.
Dust with soft dry cloth.
Do not use ammonia-based cleaning products, as they will damage the finish.
Do not leave liquids or damp cloths on this furniture.
To avoid dulling of the finish, do not place furniture in direct sunlight.
Please inspect and tighten all screws or bolts on a regular basis to ensure proper performance and safety of your item.

PRE-ASSEMBLY INFORMATION


PART DESCRIPTION

A




SIDE
QTY 1 PAIR

B




BACK BAR
QTY 7

C




SHELF
QTY 1

D




SHELF
QTY 1

E




SHELF
QTY 1

F




SHELF
QTY 1

G



SHELF
QTY 1

H




SHELF
QTY 1

NEED HELP? For help with assembly or if you are missing a part,
Please call customer service

PRE-ASSEMBLY INFORMATION


HARDWARE DESCRIPTION

1



CAM LOCK PIN
CAM LOCK
QTY 24 SETS

2




PHILLIPS SCREW
M4 X 30mm
QTY 28

3




WOOD DOWEL
M8 X 30mm
QTY 2

4






BRACKET
QTY 6


5




PHILLIPS SCREW
ROUND HEAD
M4 X 15mm
QTY 12

6

- a.  M4 X 25mm - QTY 1
- b.  M4 X 15mm - QTY 1
- c.  M4 X 25mm - QTY 1
- TIPPING RESTRAINT
QTY 1 SET




Required -
Flathead screwdriver
Phillips screwdriver
Rubber mallet
Not Included




NEED HELP? For help with assembly or if you are missing a part,
Please call customer service

COMPONENTS-KEY DIAGRAM



ASSEMBLY


STEP-1



1. Insert one Dowel (3) into pre-drilled hole on Shelf (C).
2. Use rubber mallet to tap Dowel (3) into bottom of holes securely. 1/2 length of Dowels should be exposed.
3. Attach Cam Lock Pins (1) to Side (A) using guide holes.
4. Align Cam Lock Pins with pre-drilled holes on Shelves (C, D, E, F, G, H).
5. Insert Cam Locks (1) into pre-drilled holes on Shelves (C, D, E, F, G, H).
6. Using a flathead screwdriver tighten Cam Locks into Pins.

ASSEMBLY


STEP-2



1. To attach Opposite Side (A) to Shelves (C) (D) (E) (F) (G) (H), repeat step 1.

ASSEMBLY


STEP-3



1. Attach Brackets (4) to bottom corner of Shelves (D)(E)(F) and Sides (A) using Phillips Screw Round Heads (5).
2. Use phillips screwdriver to tighten Screws.

ASSEMBLY

STEP-4




1. Attach Back Bars (B) to back of Sides (A) using Phillips Screws (2) into pre-drilled holes.
2. Use phillips screwdriver to tighten Screws.


ASSEMBLY

NOTE: Injuries and damage can occur from furniture tip-over. It is important to use the safety bracket included. If the tipping restraint kit is not in the box, please contact our customer service department in order to obtain another kit before using the furniture.

STEP-5



NOTE: The screwdriver is not included in the hardware pack.



1. To attach Tipping Restraint (6) , follow instructions on Tipping Restraint package.

When you determined the location for your unit, install the Furniture Tipping restraint. Carefully follow the instructions contained on the package.

WARRANTY

Thank you for purchasing a product. These products have been made to demanding, high-quality standards and are guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase. This warranty does not affect your statutory rights.

In case of any malfunction of your product (failure, missing parts, etc.) please contact us at our toll free service line

We reserve the right to repair or replace the defective product, at its discretion.

This product is guaranteed for 12 months if used for normal purposes. Any warranty is invalid if the product has been overloaded or subject to neglect, improper use or an attempted repair by other than an authorized agent. Heavy-duty or daily professional/commercial usage are not guaranteed.

Due to continuous product improvement, we reserve the right to change the product specifications without prior notice.

Questions, problems, missing parts?

Before returning your product
please email Customer Support

For more information visit us on our website

Like us on facebook