


ASSEMBLY INSTRUCTIONS

SEC-298 SECTIONAL

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staple used in packing



PARTS LIST


NO	SKETCH	QTY	DESCRIPTION
A		1PC	LSF Body
B		1PC	LSF Backrest
C		1PC	Console Backrest
D		2PCS	Backrest
E		1PC	Wedge
F		1PC	Left Wedge Backrest
G		1PC	Right Wedge Backrest
H		1PC	RSF Body
I		1PC	RSF Backrest
K		1PC	Console backrest

HARDWARE LIST

NO	SKETCH	QTY	DESCRIPTION
M		2PCS	Adapter
N		1PC	Power supply


STEP 1#

Insert LSF Backrest and Backrest to LSF Body then push to the end and make sure it is fixed in position securely. Then connect the wire at the back of the backrest onto the wire at the LSF Body. Align and connect the extension wire from the Console Backrest to the back of LSF Body




STEP 2#

Connect the extension cord from the LSF backrest to the back of the LSF body to activate the Massage function.




STEP 3#

Insert Left Wedge Backrest and Right Wedge Backrest to Wedge then push to the end and make sure it is fixed in position securely.




STEP 4#

Insert RSF Backrest and Backrest to RSF Body then push to the end and make sure it is fixed in position securely. Then connect the wire at the back of the backrest onto the wire at the RSF Body




STEP 5#

Connect the extension cord from the RSF backrest to the back of the RSF body to activate the Massage function.




STEP 6#

Connect the parts in order from left to right.



STEP 7#

Connect the power connector of the sofa base and the power adapter, and then plug the power adapter into the power socket.





- Disconnect the electrical plug from the wall outlet before cleaning, moving, servicing or when not in use for an extended period of time.
- Plug directly into a wall outlet. Do not use an extension cord or adaptor
- Check the condition of the power transformers, electrical cords, plugs and connectors monthly. Keep the power adaptor and electrical cords away from heat sources. Never operate the unit with a damaged power adaptor, electrical cord, plug or connector.
- Before moving the product, please disconnect the electrical plug from the wall outlet and secure the mechanism to prevent unexpected opening or movement. Never move the product by the mechanism, legrest, handle, or reclining back. Do not attempt to disassemble or service the adaptor or motor. No serviceable parts are inside.
- Do not allow electrical cord to be pinched between moving parts or between the frame and the floor.
- Do not place cord under carpet or in location where it could become worn.
- Unplug the power cord immediately if you detect strange odors or fumes coming from the chair.

PLEASE KEEP ASSEMBLY INSTRUCTION FOR FUTURE REFERENCE