














ASSEMBLY INSTRUCTIONS

Thank you for purchasing our product.



MAIN PARTS LIST				
A x1 Backrest 	B x1 Seat 	C x1 Base 	D x1 Mechanism 	E x1 Gas lift 
F x5 Casters 	G-L x1 Armrest Left 	G-R x1 Armrest Right 	H X1 Set Gas lift Cover 	


LIST OF HARDWARE				
PART	QTY	ITEM	USE FOR	
I	4	M6x20	Mechanism	
J	8	M6x25	Armrests	
K	8	Armrest Covers	Armrests	
L	1	Allen Wrench		

BEFORE YOU START THE ASSEMBLY, PLEASE READ THE FOLLOWING TIPS AND WARNINGS.

1 Do a quick inventory to make sure the package contains all the parts and hardware listed in the assembly instructions.



6 Do not overtighten or force the screws as they might break, strip, damage the threads of the holes or get stuck inside the part.



2 Missing, damaged and defective parts can be replaced at no cost to you. Please refer to the last page in this manual.




7 If the hole seems too big or too small for the screw, first make sure you are using the correct size of screw and that it's been installed in the correct hole. Test another of the same screw into the same hole, as well as test the screw onto different holes for the same part. If the hole still appears to be too small, do not force it, it needs replacing.




3 On each step read the instructions and analyze the illustrations thoroughly before proceeding to do the assembly.



4 Make sure you understand which hardware will be used on each step. Using the wrong size of screw, bolt or pin might strip the threads or cause damage to the part in which it is being used.




5 To avoid misalignments, always leave the screws loose and tighten them until all pieces are positioned correctly.



ASSEMBLY STEPS

STEP 1

Insert all the casters **F** into the base **C** using pressure, then place the gas lift **E** in the middle of the base **C** and cover it with **H**.




STEP 2

Hardware

I	 M6x20	4 Pcs
---	--	----------


L	
---	---

Assemble the mechanism **D** to the seat **B** with screws **I**, making sure the knob faces towards the front.



STEP 3

Put the seat over the base parts making sure the tip of the gas lift **E** enters into the hole of the mechanism **D**.



STEP 4

Hardware

J




4
Pcs

L



Assemble the armrests **G** to the seat **B** on their respective sides using screws **J**. Screw them loose and do not tighten them to allow flexibility for the next step.



STEP 5

Hardware

J



4
Pcs

K




8
Pcs

L



Assemble the backrest **A** to the armrests **G** with screws **J**. Proceed to tighten all the screws, and cover the holes with **K**.



ALL DONE!

Give yourself a nice pat on the back.
You did a great job!

CHAIR'S FUNCTIONS

- ① To raise or lower the chair's height, pull UP the lever that is under the seat. The chair goes down while sitting on it, or up if you lift your body.
- ② To make the chair tilt freely, pull the same lever OUT horizontally to unlock this function. When the chair is in the normal upright position, push the lever IN to lock again.
- ③ To adjust the tension for the tilting function, turn the mechanism's knob in either direction to apply more or less tension. With less tension, the tilting will feel easier.
- ④ Pivot the armrests UP to use the chair as if it was armless.



WARNINGS

- Do not exceed the indicated weight limit.
- Do not stand up on the chair or use it as ladder.
- Use the chair to sit only one person at a time.
- Do not use the chair if parts are damaged or if screws are loose or missing.
- Do not sit near the edge of the seat and always sit properly on the chair to avoid going beyond your balance point and fall off the chair.
- The chair is intended for teenagers and adults. If small children are using the chair, please keep close observation on them.
- Do not allow small children to play with the chair.
- Not paying attention to these warnings could result in severe injuries.

CARE AND MAINTENANCE

- To clean the chair it is recommended to use a soft cloth lightly damped in a solution of smooth soap and water, then dry with a clean towel.
- Do not use solvents or abrasive materials to clean any part of the chair.
- Before applying a cleaning agent, test on a small hidden area of the chair, like underneath the seat.
- Do not expose the product to direct sunlight or to extreme environmental conditions.
- Every 4 months, inspect the chair completely and make sure that all screws are tighten.

TECHNI MOBILI CHAIR WARRANTY
TASK/KID'S CHAIR: 1-YEAR WARRANTY
EXECUTIVE/MANAGER CHAIR: 2-YEAR WARRANTY

1. This warranty is expressly limited to the repair or replacement (at its option) of defective chair components or materials that fails under normal use as a result of a defect in materials or workmanship. This warranty is limited to merchandise purchased in the Continental United States. No assembly labor is included. The word "defects" as used in this warranty, is defined as imperfections that impair the utility of the product.
2. This warranty applies under conditions of normal use, but does not apply to defects that result from intentional damage, negligence, unreasonable use or exposure.
3. Liability for consequential damages is excluded to the extent exclusion is permitted by law. This warranty gives you specific legal rights, and you may have other rights that vary from State to State.
4. Products does not warrant: a) natural variations in character marks b) changes in surface finishes due to aging or exposure to light c) marks, scars, or wrinkles occurring naturally in leather d) failure resulting from normal wear and tear e) the matching of colors, grains, or textures of natural materials f) the colorfastness or the matching of textiles, including an exact match to cuttings or to swatch cards g) damage, marking, or staining of veneer surfaces due to contact with rubber or similar compounds, damage from sharp objects or imprinting from writing instruments, or prolonged exposure to direct sunlight h) we do not warrant products that are exposed to extreme environmental conditions or that have been subject to improper storage.
5. Products shall not be liable for loss of time, inconvenience, commercial loss, or incidental or consequential damages.
6. Any modification to the original product voids the warranty. We do not warrant the performance of the product when used in combination with other than original products.
7. This product has been designed for and is intended for office and home-office use only. This warranty is Original Purchaser's sole remedy for product defects, and this warranty does not extend to any product, or damage to any product, caused by or attributed to abuse or misuse, products used for commercial or rental purposes, use modifications of, or attachments to the product, and products or parts not used, maintained, or extended hereunder is in lieu of any and all other warranties, express or implied, including without limitations any implied warranty or merchantability or of fitness for a particular purpose.