
# GLASS DISPLAY CABINET



# **CAUTION**

Tips to be aware of before installation

#### 1. Handle with care

Tempered glass is a fragile material and requires careful handling. Please handle this product with care to prevent damage, as a damaged edge or scratched surface can cause the glass to crack suddenly, although it will not break into sharp fragments, only small pieces. Avoid collisions from the side, as this is the most fragile part of the glass.

### 2.Prevent tipping-over accidents

It is important to note that furniture tipping-over can result in injury or death to the installer. Always secure this product permanently to the wall to prevent accidents.

#### 3. Suitable wall types

The pack includes a wall mount suitable for wooden walls, screws, and a plastic screw accessory (optional). For solid walls, please drill holes with a hammer and then insert the screws and plastic accessories. However, the included wall mount is not suitable for walls with weak holding force, such as plasterboard. To attach this product to plasterboard, please make sure the screws are securely fastened to the keel. Please choose the proper safety devices according to the type of wall in your house.

#### 4. Wear protective gear

When installing this product, please wear gloves, long-sleeved shirts, pants, and socks to avoid injury. Keep children away from the installation area and ensure that the installation is done by two adults.

#### 5.Use buffer layer

Use cardboard or carpet as a buffer layer during installation to prevent the glass corner from colliding with hard objects such as the floor. This is especially important when installing tempered glass, as the corners should not hit the floor to prevent the glass from shattering.

#### 6.Install anti-tip device

When installing a display case, always install the anti-tip device first to avoid the risk of serious or fatal injury. Keep children at least 2 meters/6.6 feet away from the display case. The display case must be permanently attached to the wall to prevent it from tipping over. Wall mounting is not limited to the fixtures we offer, and you are free to install similar fixtures to avoid possible hazards.

## 7.Install door lock for display case

Avoid operating the cabinet door frequently and shaking the cabinet, as this may cause the cabinet door to collide with objects or drop items. Additionally, install a door lock to prevent accidental operation by children.


#### 8.Not fireproof


The top/bottom panel of this cabinet is made of MFC/PVC-covered particle board, which is not fireproof. When disposing of this product, please contact the relevant local authorities or qualified companies.


## 9.Adjust footrest and note load capacity


Please adjust the footrest on the product after installation, and note that the maximum load of the glass plate is 5.00 kg/11.00 lbs. The load capacity is for stored items only. Check and tighten all screws after installation. Product dimensions may have a tolerance of 10 mm/0.4 inch due to different measuring tools or methods. After installing the cabinet, check and tighten all screws to avoid potential safety hazards, such as shelves falling and cabinet structures becoming loose due to loosen screws.


# PRODUCT COMPONENT LIST






















# 



# 



After installation, it must be anti-tipping device to a solid wall to prevent tipping and shaking!

