

TEKWOOD Cleaning & Care



DESCRIPTION

Tekwood is a wood-alternative material developed from polystyrene, an HDPE material with foam additives. Tekwood is available as an option for this Collection in either natural or vintage finish. Designed for the outdoors, Tekwood provides the look and feel of wood with minimal weathering or maintenance.

CARE AND MAINTENANCE

Tekwood products should be cleansed using a mild, non-abrasive cleanser and rinsed well. Over time, Tekwood's color may darken slightly if exposed to sun and other natural elements. This process cannot be reversed, but does not affect the structural integrity or aesthetic of the product. To prolong this process, this manufacturer recommends bringing furniture indoors or covering when not in use or during non-seasonal months. Tekwood has the potential to stain. To help prevent staining, use a furniture polish or protectant that is labeled safe for plastic materials prior to use.

SUN EXPOSURE DISCLAIMER

When exposed to direct sunlight, magnification from the sun can cause burn marks on Tekwood. To avoid these burn marks, do not use certain glass or stemware that could increase the magnification. Also, avoid leaving lighters, matches or cigarettes directly on Tekwood.



GENERAL CLEANING

Tekwood can be cleaned with a cloth using most any household cleaning solution, even dish washing liquid. Rinse well after cleaning.

* Recommended
303 Indoor and Outdoor Furniture Cleaner



DEEP CLEANING

For stubborn grease stains, scrub lightly following general cleaning instructions, using Scotch-Brite Scour Sponge or Heavy Duty Scour Pads.



PROTECTION

A routine application of a furniture polish or protectant that is labeled safe for plastic materials is recommended to provide resistance to stains.

* Recommended
303 Indoor and Outdoor Furniture Cleaner