

TEAMSON HOME


Peaktop Loveseat Bench PT-OF0030














^{**} Got questions? Please have your product code (on the first page of this instruction, e.g. TD-12345A) and the order number ready, give us a call or email us through our customer care support! We are always ready to assist you!

TEAMSON HOME



Warranty sign up

www.teamsonhome.com

Serving you well gives us great joy!

USA ·····+1(800)935-3959

Mon - Fri 10:00am ~ 2:00pm EST ⊠ support@teamson.com

EU/UK···+44(0)1952-916-050

Mon - Thu 9:00am ~ 5:00pm GMT Friday 9:00am ~ 4:00pm GMT ⊠ support@teamson.co.uk

ASIA ···· 深圳区公室:

+86(0755)8885-3558.分机号108

Mon - Sat 9:00am ~ 5:00pm GMT+8

⊠ sales_ec@teamson.com


台北辦公室:

+886(2)2556-6268

Mon - Fri 9:00am ~ 5:00pm GMT+8


□ sales_ec@teamson.com

Exploded Drawing





Product Parts







WARNING:


- 1. Do not let any sharp objects touch or rub the surface of the product.
- 2. When assemblying, do not let children play around the working area.
- 3. Please confirm all parts are correct before starting the assembly process.
- Do not tighten all bolts and screws completely until the entire unit has been assembled and set up.

Hardware










Step 3 4 pcs 4 pcs 4 pcs B

Step 4








X1

Step 5 2 pcs 2 pcs 4 pcs E 4 pcs

Step 6







X1