

2600-260 : DRESSER
2610-260 : DRESSER**Assembly Instruction****A. Component :**

Qty

1. Dresser


1 Pc



A



B



C



D



E

B. Hardware :

Qty

A. Screw Ø8 x 2"

1 Pc

B. Screw Ø8 x 5/8"

1 Pc

C. Restrain Strap


1 Pc

D. Metal Tabs

2 Pcs

E. Plastic Wall Anchor

1 Pc

**⚠ WARNING****Children have died from furniture tipover. To reduce the risk of furniture tipover:**

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

*This is permanent label.
Do not remove !*