


## How to choose the size?

Choose the door panel size that suite you



Door Size	Fit Opening Width	Fit Opening Hight
24" x80"	≤22"	≤78"
28" x80"	≤26"	≤78"
30" x80"	≤28"	≤78"
32" x80"	≤30"	≤78"
36" x80"	≤34"	≤78"
48" x80"	≤44"	≤78"
56" x80"	≤52"	≤78"
60" x80"	≤56"	≤78"
64" x80"	≤60"	≤78"
72" x80"	≤68"	≤78"