ASSEMBLY INSTRUCTIONS



Dining Table

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A TOP




1PC

C STRETCHER

2PCS

B2 (BOX 2)

B LEG FRAME



2PCS


HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED (B1)


1	SHORT BOLT WITH WASHER (M6 x 40mm - BLK)	8PCS
2	LONG BOLT WITH WASHER (M6 x 60mm - BLK)	2PCS
3	HEX NUT (5/16 - GD)	2PCS
4	LOCK WASHER (M8 X 13mm - GD)	2PCS
5	FLAT WASHER (M8 X 22mm - GD)	2PCS
6	ALLEN WRENCH (M4 - GD)	1PC
7	WRENCH (12.8 - GD)	1PC

ASSEMBLY INSTRUCTIONS STEP 1 B


Protective surface



ASSEMBLY INSTRUCTIONS STEP 3







Note: Dimension tolerance ±5%