Floor lamp

■Specification


Voltage: 110-130V
Wattage: 100 Watt Max
Material: Meta
Lamp holder: E26
Bulb info: A19 9W 2700K
Switch type:ON/OFF
Wire Length: 96in/2440mm
Usage: Indoor use only

■Package Include


1 x Lampshade
1 x Lamp Base
2 x Metal rings
1 x Finial&Harp
1 x A19 Led Bulb
1 x User Manual

■Easy Installation

1.Fasten Socket Assembly into Lampbody be careful not to twist power cord.
2.Fasten Socket Assembly into Tube(A) be careful not to twist power cord.
3.Fasten Tube(A) into Tube(B)be careful not to twist power cord.
4.Fasten Tube(B) into Tube(C) be careful not to twist power cord.
5.Fasten Tube(C) onto Base be careful not to twist power cord.
6.Attach two legs of the lamp harp to the saddle.
7.Install the bulb.
8.Put the 4 support frames on the lower ring to the upper ring.
9.Fix the lampshade on the lamp harp.
10.Screw the finial to secyre the lampshade.（When the lampshade is tilted, refer to the lampshade adjustment instructions below.）



■ Adjust the angle of the lampshade
A.Adjust the angle in the forward direction
B.Adjust the angle from the side
Refer to Figure A&B



■ Attention

1.If you want to replace the included 2700K vintage LED bulb, it is recommended to use an incandescent bulb or LED bulb with a maximum wattage of 60 watts.
the lamp, so it may cause to flicker or lose dimming function with other Led bulbs.
2.The bulb will increase the brightness when it is reaching its lifespan or has partial short-circuit. At that moment, please switch off, change a bulb and use it as you would normally.
3.Please shut off the power and unplug it before you screw in a new bulb.
4.Don't put the lamp in overheating working condition or cast it into fire.