











Brightech® Emma Assembly & Free Extended Warranty Instructions

A  1PC	B  1PC	C  1PC	D  1PC	E  1PC	F  3PCS	G  3PCS	H  3PCS
--	--	--	--	--	---	---	---



1. Screw the leg parts into one another. Place the shade on the lamp body. Secure the lamp shade with ring (D). See separate shade assembly instructions.



2. Make sure the shade is supported by the metal support as the above close-up shows.

Extend Your Warranty From 3 Years To 5 Years

To extend your warranty by 2 extra years for a total of 5 years' warranty, register your purchase by filling in the brief form at <https://www.brightechshop.com/pages/extended-warranty/>.

Customer Service

Thank you for your purchase of your Brightech lamp.

Please contact us via our website or email if you have any issues or concerns.

www.brightechshop.com

wecare@brightechshop.com

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. **DO NOT ALTER PLUG.**

Max Wattage: 150 watt incandescent or 42 watt CFL equivalent.

A 9.5 watt LED bulb is included. (Incandescent/CFL not included)