


CERAMIC GARDEN STOOL

Review this manual before use and save it for future reference.



GENERAL USE & CARE

Multi-functional garden stool can be used indoors and outdoors.



SAFE USE: Only use on a flat, level surface. Do not exceed the weight capacity.

MOVING: Always lift the bottom. Slowly and gently set the stool down to prevent breakage.

CLEANING: Clean with a damp cloth; do not use chemicals or abrasive materials as they may damage the glaze.

STORAGE: Avoid extreme temperatures and store indoors during periods of freezing weather.

Any modification to the product or failure to follow recommended care will void the product warranty.

⚠️ WARNING: Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

