

LED DECORATIVE CEILING FIXTURE




INSTRUCTIONS PERTAINING TO RISK OF FIRE OR INJURY TO PERSONS
READ ALL INSTRUCTIONS

IMPORTANT SAFETY INSTRUCTIONS

SAVE THESE INSTRUCTIONS







TOOLS AND MATERIALS REQUIRED:



SAFETY PRECAUTIONS:

1. TURN OFF ELECTRICAL POWER BEFORE STARTING INSTALLATION OF LIGHT FIXTURE.
2. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.
3. CAUTION-RISK OF ELECTRIC SHOCK. CONSULT A QUALIFIED ELECTRICIAN TO ENSURE CORRECT BRANCH CIRCUIT CONDUCTOR.

INSTALLATION

 Metal Ring Lens Fixture	1. Remove plastic lens by gently rotating the decorative knobs counter-clockwise and remove metal ring, then lift the lens.
 Electrical Outlet Box Mounting Screws	2. Place mounting screws (included) in electrical box screwing in halfway.
 Black Ground White	3. Using wire nuts to connect ground wires (green) from Fixture to ground wire out of electrical box. Connect black wire from fixture to black wire from electrical box. Connect white wire from fixture to White wire from electrical box.
 Black Ground White	4. Attach fixture to mounting screws, turn fixture counter-clockwise to lock. You may adjust magnet PCB board light source.
	5. Secure fixture by tightening mounting screws.
 Fixture Lens Metal Ring	6. Place acrylic lens over the fixture pan. Place the metal ring over the acrylic lens lining up the holes with the fixture pan posts and then secure it with the decorative knobs included.