Parts List



Adjustable Rod



Extension Rod



Coat hanger



Base




Allen Wrench



M6 Screw


Floor Standing Garment Rack Installation Guide

1




Screw the extension rod onto the base

2




Screw the extension rod and the telescoping rod together

3



Attach the hanger onto the rod and tighten the screws.

4



wist the inner rod to the left to lock it in place

tips： Adjust the height as needed