





























ASSEMBLY INSTRUCTION
This installation manual is the correct version

Note: Distinguishing between the numbers 6 and 9 is different, with the number 9 underlined; Please tighten all screws by 60% first, and then tighten them by 100% after installation is complete.




1.x2	2.x2 	3.x2 	4.x2 	5.x2 
6.x1 	7.x1 	8.x1 	9.x1 	10.x10 
11.x1 	12.x1 	13.x10 	14.x4	15.x6 
16.x1 	17.x1 	18.x2 	19.x10 	20.x1 
A.x16pcs  M8x55mm	B.x32pcs  M6x60mm	C.x1pcs  M6x50mm	D.x33pcs  M6x35mm	E.x8pcs  M8
Fx4pcs  M6	G.x16pcs  M8x16mm	H.x70pcs  M6x16mm	I.x1pcs  M6	J.x1pcs  M8
K.x1pcs  5#	L.x8pcs  40x40mm	M.x2pcs  M6	N.x1pcs  4#	O.x60pcs 
P.x4pcs 	Q.x2 	R.x1 	S.x4  M8	V.x2 	W.x4 20x40mm

①





x2

②




x2



3
L
I
F
H
H
B
K
x2
1
B
2
L
H
B
K
x2
x2


4
K
G
A
x4
E
J
6
7


5




6




7




8




⑨




⑩




11




12




13




14



15



16



⑰

