


Product Usage Instructions












NO JUMPING





INSTALLATION GUIDE



Suggest using electric tools for installation


SKU:16036S

















SKU:16037S


SKU:16038S





2
3
3A
4
6
9
12
3
4
7
10A
10B
14
5
11
15
17
18
1A
1B
8
13
16
21
19
22
31A
31B
20
27
25
26
23
24
30
29
28
29
29



A		65 PCS	M	 M50	1 PCS
B	 M15	65 PCS	O	 O-1 O-2	2 PCS
C	 80*80	6 PCS	P		1 PCS
D	 M8*40	13 PCS	Q		6 PCS
E	 M4*30	25 PCS	R	 M6*13	25 PCS
F	 M3.5*14	130 PCS	S	 M6*18	8 PCS
H	 M4*12	8 PCS	T	 T00L	1 PCS
I		4 PCS	W		2 PCS
J	 J-1 J-2	2 PCS	X	 M15*150	4 PCS
K		12 PCS	Z		2 PCS
L		8 PCS			

SpeciaI hardware instaII instructions





Special hardware removal instructions




A		8 PCS	B	 M15	8 PCS
M	 M50	1 PCS			


STEP 1




A		8 PCS	B	 M15	8 PCS



STEP 2




A		8 PCS	D		4 PCS
B	 M15	8 PCS			


STEP 3




P		1 PCS	F	 M3.5*14	2 PCS
C	 80*80	2 PCS	R	 M6*13	8 PCS
A		10 PCS	D		4 PCS


STEP 4






A		4 PCS	B	 M15	14 PCS


STEP 5









F	 M3.5*14	10PCS	O	 O-1	2 PCS
Q		6 PCS			


STEP 6







A		10 PCS	B	 M15	10 PCS
F	 M3.5*14	8 PCS	O	 O-2	2 PCS
D		4 PCS	J	 J-2	2 PCS


STEP 7




A		2 PCS	B	 M15	2 PCS
F	 M3.5*14	6 PCS	K		3 PCS


STEP 8




A		6 PCS	B	 M15	6 PCS


STEP 9




A		2 PCS	B	 M15	2 PCS
F	 M3.5*14	6 PCS	K		3 PCS


STEP 10








A		6 PCS	B	 M15	6 PCS


STEP 11




E	 M4*30	8 PCS	K		6 PCS
F	 M3.5*14	12 PCS			

STEP 12




E	 M4*30	8 PCS			

STEP 13



E	 M4*30	8 PCS			


STEP 14




The direction of the red arrow is forward


H	 M4*12	2 PCS	W		2 PCS
S	 M6*18	8 PCS			


STEP 15




H	 M4*12	4 PCS	I		4 PCS
C	 80*80	2 PCS	R	 M6*13	8 PCS

STEP 16






Install iron plate first, then install pull handle





C	80*80	2 PCS	R	M6*13	8 PCS

STEP 17





STEP 18






STEP 19



outer rail
NO/1
outer rail
NO/2
outer rail
Inter rail
NO/3


19
21
22
20


24
27
26
23
24


F	M3.5*14	80 PCS	L		8 PCS
X	M15*150	4 PCS			

STEP 20




F	M3.5*14	4 PCS	J	J-1	2 PCS
Z		2 PCS			

STEP 21



STEP 22



When opening or closing, it is advisable to push and pull simultaneously with both hands.