

ASSEMBLY INSTRUCTIONS COUNTER DINING TABLE





NOTE TO CUSTOMERS:

- For ease and speed of assembly we recommend that before you commence each step of the assembly that you identify all the parts required to complete that step.
- We recommend that where possible you allow sufficient space to assemble the item as close as possible to the place where it will be once assembled.
- For the protection of your furniture we recommend that the product is placed on protected surfaces during assembly to prevent any damage.
- During assembly do not over tighten the screws or bolts, as this may damage the product.
- Please ensure you retain all the product packaging until the item is completely assembled.
- Periodically check all fitting and re-tighten as necessary.
- Never allow any liquids to remain on your furniture as absorption can cause the wood to warp or finish to de-laminate.
- It is recommended that this item should be assembled by two adults.


	DARTS	IDENTIFICATION	
A-	Glass Table Top		1 pc
B-	Leg Frame (Left)		1 pc
C -	Leg Frame (Right)		1 pc
D-	Storage Top Panel		1 pc
E-	Storage Bottom Panel		1 pc
F-	Rails (Front & Rear)		2 pcs
G-	Storage Back Panel		1 pc
Н-	Door		1 pc
I-	Upper Shelf Panel		1 pc
HARDWARE IDENTIFICATION			
1-	JCBC Bolt M6 x 50mm	Ø8mm ((1) 2 "	4 pcs
2-	Spring Washer	<u>2</u>	4 pcs
3-	Allen Key		1 pc
4-	Minifix Connecting Bolt		8 pcs
5-	Minifix Connector Housing		8 pcs
6-	Magnet Door Catch		1 pc
7-	Door Knob		1pc
8-	Screw M4 x 25mm	Ø4mm ««««««««««««««««»»»» **	1 pc
9-	Pivot Hinge		2 pcs
10-	Glass Support		4 pcs
11-	Bolt for Glass Support		4 pcs
NOTE: Quantities shown are for one table.			







Turn the assembled leg part upright position, and assemble Rail (F) to the both leg frames (C) & (B).



STEP 4

Slide Back Panel (G) into the grooves until fit into the bottom panel.

