
## **ASSEMBLY INSTRUCTIONS**

Compression must wait for 72 hours before it can be unfolded, and it needs to be flapped by hand



W2108133937/W2108133953 W2108133938/W2108133954 W2108133939/W2108133955 W2108133940/W2108133956 W2108133941/W2108133957 W2108133942/W2108133958 W2108133943/W2108133959

- 1. Thank you for choosing our products.
- 2. Return Policy



DO NOT RETURN TO THE STORE! Skip the process of returning your product and contact us directly for a replacement

If you find that parts of your order are missing or damaged, we will gladly ship any needed replacement parts free of charge.

If your product's quality does not meet your expectations or you have found any sort of defect, please contact our customer service department and let us know the details of your order and any issues encountered, we will try our best to provide you with a solution. Feel free to also directly contact our manufacturer concerning needed replacement parts and they will be happy to help provide you with a solution or answer any questions you may have.

## **Recommendations** Before Beginning Assembly

- Read instructions, cover to cover
- ★ Have 2-4 adults on hand for assembly depending on product size
- Do not assemble directly on flooring or carpet
- Assemble on a clean non-marring surface (example: packing foam)
- Save all packaging until finished
- 3. Assembly Notice:
  - If you encounter any problems during assembly and find that you cannot continue, rest assured we will help you solve the situation as soon as possible. Simply keep all of the

parts of the product stored in a safe place and contact us immediately so we may assist you further.

- Once you have opened your package, remove all inner hardware packages and take the parts out. One by one, Place the parts out neatly in front of you, then refer to the instructions to ensure no parts are missing. If any pieces are found missing, please carefully look in the box first, as the hardware packaging might have torn making the hardware spill in the box.
- Some key parts of your product may be stored and hidden inside of other parts. Please open any zippered or hook & loop storage compartments to remove all parts. (example: cushions and legs being stored in the underside of a sofa)
- ☑ IMPORTANT: When setting up your product, DO NOT INSTALL THE SCREWS ALL THE WAY IN THE BEGINNING. Place each screw into their proper hole and use your hand to twist the screw halfway. Twist all the screws in halfway to ensure the holes will match up properly and the product is level on the ground. When everything seems fitted, then tighten the screws.
- When you have completed assembly, we suggest you have more than one person to assist you with lifting and placing the product.

## Care & Maintenance

- Do not put hot items directly on furniture surface
- Do not clean furniture with harsh cleansers or polish
- Do not place furniture under direct sunlight
- ◎ Do not place furniture near heating or cooling vents
- Do not write on furniture without a padded barrier to protect the surface
- Do not place furniture outside. For indoor use only
- Stains may be removed with mild soap solution and damp cloth

∞ 🕅 ● Children should not climb or jump on the furniture

Dust and pick-up spills using a clean, non-colored, lint-free cloth

Caution

• This product contains small components. Please ensure that they are kept away from small children.

• Do not use power tools to assemble your furniture. Power tools may strip or damage the parts.



PART LIST:					
A		2PCS	W2108133937/W2108133953: Bx1 lx1 Fx1 Kx1 Nx1 W2108133938/W2108133954:		
В		1PCS	Cx1 Ix1 Fx1 Kx1 Nx1 W2108133939/W2108133955: Dx1 Ix1 Fx1 Kx1 Nx1 W2108133940/W2108133956: Dx1 Ix1 Fx1 Kx1 Nx1 W2108133941/W2108133957: Ex1 Jx1 Lx1 Mx1		
С		1PCS			
D		2PCS	W2108133942/W2108133958: A x 2 O x 24 P x 32 Q x 32 R x 1 S x 24 T x 24 W2108133943/W2108133959: G x 1 H x 1		
E	e	1PCS	0		24PCS
F		4PCS	Р		32PCS
G		1PCS	Q	0	32PCS
н		1PCS	R		1PCS
I	Big	4PCS	S		24PCS
J	Small	1PCS	Т		24PCS
к		4PCS			
L		1PCS			
М		1PCS			
N		5PCS			

