




ASSEMBLY INSTRUCTIONS
OCCASIONAL TABLES

OCCASIONAL TABLES

PARTS & HARDWARE LIST














NOTES:

1. CHECK CAREFULLY FOR SMALL PARTS WHICH MAY COME LOOSE DURING SHIPMENT.
2. REMOVE ALL COMPONENTS FROM THE PACK AND PLACE ON A CLEAN, SOFT SURFACE TO ASSEMBLE.
3. UNITS SHOULD BE ASSEMBLED BY TWO OR MORE PEOPLE.
4. DO NOT OVER - TIGHTEN SCREW/ BOLTS UNTIL ASSEMBLY IS COMPLETED.
5. WITH USE, SCREW/ BOLT MAY BE COME LOOSE & MUST BE TIGHTENED PERIODICALLY.



OCCASIONAL TABLES

PARTS & HARDWARE LIST

<p>(A)</p>  <p>COCKTAIL TABLE TOP x 1</p>	<p>(B)</p>  <p>COCKTAIL TABLE LEGS x 4</p>	<p>(C)</p>  <p>COCKTAIL TABLE BASE ROUND METAL x 1</p>
<p>(D)</p>  <p>END TABLE TOP x 2</p>	<p>(E)</p>  <p>END LEGS x 8</p>	<p>(F)</p>  <p>END TABLE BASE ROUND METAL x 2</p>
<p>(G1)</p>  <p>ALLEN BOLT x 12 (Ø1/4" *15 MM)</p>	<p>(G2)</p>  <p>ALLEN BOLT x 24 (Ø1/4" *30 MM)</p>	<p>(G3)</p>  <p>SPRING WASHER x 36 (Ø5/16")</p>
<p>(G4)</p>  <p>FLAT WASHER x 36 (Ø5/16")</p>	<p>(G5)</p>  <p>ALLEN KEY x1(M4)</p>	


NOTES :

1. CHECK CAREFULLY FOR SMALL PARTS WHICH MAY COME LOOSE DURING SHIPMENT.
2. REMOVE ALL COMPONENTS FROM THE PACK AND PLACE ON A CLEAN, SOFT SURFACE TO ASSEMBLE.
3. UNITS SHOULD BE ASSEMBLED BY TWO OR MORE PEOPLE.
4. DO NOT OVER - TIGHTEN SCREW/ BOLTS UNTIL ASSEMBLY IS COMPLETED.
5. WITH USE, SCREW/ BOLT MAY BE COME LOOSE & MUST BE TIGHTENED PERIODICALLY.




OCCASIONAL TABLES

STEP 3 (x1) COCKTAIL TABLE ASSEMBLY




OCCASIONAL TABLES

STEP 2 (x1) COCKTAIL TABLE ASSEMBLY




STEP 3 (x1)



COCKTAIL TABLE ASSEMBLY COMPLETED

OCCASIONAL TABLES


STEP 4 (x2) END TABLE ASSEMBLY



OCCASIONAL TABLES

STEP 5(x2)

END TABLE ASSEMBLY



STEP 6 (x1)




TABLE ASSEMBLY COMPLETED