



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

503991-SET
SECTIONAL 3 PC SET

ITEM: 503991-SET



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

3MINUTES

PARTS IDENTIFICATION

503991B1(BOX 1)

A LEFT SIDE SOFA



1 PC

B RUST PILLOW



1PC

C EBONY & WHITE PILLOW



1PC

503991B2(BOX 2)

D RIGHT SIDE SOFA



1 PC

B RUST PILLOW



1PC

E PEARL GREY PILLOW



1PC





503991B1



503991B2




503991AC



ITEM: 503991-SET

ASSEMBLY INSTRUCTIONS

PRODUCT DIMENSION



Note: Dimension tolerance $\pm 5\%$

