
# **Assembly Instructions**



## **ASSEMBLY RATING**


The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY OOOODIFFICULT

Tools Required For Assembly:

Allen Wrench

Phillips Screwdriver







## **ASSEMBLY & CARE ADVICE**

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


#### BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.



Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor. No dragging of products/parts.



Some furniture comes with height adjusetment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.





Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.





Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

### **Hardware Pack in Headboard**




#A x 1pc Allen Wrench



#D x 6pcs M6 Flat Washer



#B x 6pcs JCBC 35mm



#E x 1pc AC Adapter



#C x 6pcs M6 Lock Washer

## **Hardware Pack in Side Rail**



#F x 1pc
Allen Wrench




#G x 16pcs JCBC 5/16" x 20mm



#H x 16pcs M8 Lock Washer



#I x 16pcs M8 Flat Washer



Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

### **Hardware Pack in Footboard**




#J x 1pc Allen Wrench



#R x 26pcs Screw 32mm



#K x 2pcs JCBC 16mm



#S x 4pcs Adjustable Leveler



#L x 9pcs JCBC 35mm



#M x 3pcs JCBC 60mm



#N x 14pcs M6 Lock Washer




#O x 7pcs M6 Flat Washer




#P x 4pcs 1/4" Flat Washer




#Q x 2pcs Screw 16mm




Page 6 of 11




Page 7 of 11



#Prepare 4 bolts assembly by inserting lock washer (#N), then 1/4" flat washer (#P) onto bolts (#L). Align drawer base panels (#8) to the holes of the footboard (#4). Secure by using bolts (#L).



Page 9 of 11



Page 10 of 11

