

Assembly Instructions

Caution: You must read these Assembly Instructions before you proceed

Care & Maintenance



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- To obtain the longest lifespan of your outdoor product minimizing exposure to direct sunlight is recommended.



- Children should not climb or jump on the furniture.



- Do not write on furniture without a padded barrier to protect the surface.



- To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.



- Not for commercial use. For residential use only.




- Stains may be removed with mild soap solution and damp cloth.



- Dust and pick-up spills using a clean, non-colored, lint- free cloth.

Please look into the **Seat Panel** for hardware packs.

Swivel Chair










Caution: This Chair is NOT a TOY.






Keep your child/children at bay during the assembly process.

Whenever lifting or moving the Chair and to prevent damage to the Chair, two adults may be needed to execute these actions.

Part List

Label	Picture	Description	Qty
A		Left Leg Panel	1
B		Right Leg Panel	1
C		Backrest Panel	1
D		Seat Panel	1
E		Support Seat Panel	1
F		Leg	2
G		Support Bar 1	2

Part List


Label	Picture	Description	Qty
H		Support Bar 2	2
I		Support Bar 3	1
J		Turntable	1
K		Seat Cushion	1
L		Back Cushion	1

Hardware


No.	Picture	Description	Qty
①		Screw (M7x40mm)	9
②		Screw (M6x70mm)	5
③		Screw (M7x90mm)	17
④		Allen Wrench	2

Assembly Preparation


Before Beginning Assembly:




Ax1




Bx1




Cx1




Dx1




Ex1




Fx2




Gx2




Hx2




Ix1



Jx1



Kx1



Lx1

①



x9

②



x5

③



x17

④



x2



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Overview




This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1



Unpack and place all parts on a clean, non-marring surface.

Step 2




Place the Leg (F) upright as shown in the picture above onto a clean, soft surface to avoid any scratches or damages to the product.

With assistance from your adult partner, attach the Support Bar 1,2 (G),(H) to the Leg (F) using Screws (3) with Allen Wrench (4) as shown above.

Do not fully tighten the Screws.


Step 3



Turn the Leg (F) (bottom-side up) and place it on a clean, soft surface to avoid any scratches or damage to the product.


Attach Support Bar 3 (I) to the Leg (F) as shown above.

Step 4




With assistance from your adult partner, attach the Leg (F) to the Support Bar 1,2 (G),(H) and Support Bar 3 (I) to the using Screws (③) with Allen Wrench (④) as shown above.
Do not fully tighten the Screws.

Step 5



Rotate the Turntable (J) 90° as shown in the image. Connect the Turntable (J) to the Support Bar 3 (I) using Screws (①) With the Allen Wrench (④) as shown above.
Fully tighten the Screws.

Step 6




Place the Left Leg Panel (A) upright as shown in the picture above onto a clean, soft surface to avoid any scratches or damages to the product.

With assistance from your adult partner, attach the Support Seat Panel (E) to the Left Leg Panel (A) using Screws (3) with Allen Wrench (4) as shown above.

Do not fully tighten the Screws.


Step 7



With assistance from your adult partner, attach the Backrest Panel (C) to the Left Leg Panel (A) using Screws (3) with Allen Wrench (4) and Seat Panel (D) to the Support Seat Panel (E) as shown above.

Do not fully tighten the Screws.

Step 8




Flip Chair 90° as shown in the image.

With assistance from your adult partner, attach the Right Leg Pane (B) to the Backrest Panel (C) and Support Seat Panel (E) using Screws (③) with Allen Wrench (④) as shown above.

Do not fully tighten the Screws.

Step 9




Flip Chair 90° as shown in the image.

With assistance from your adult partner, attach the Support Seat Panel (E) to the Seat Panel (D) using Screws (②) with Allen Wrench (④) as shown above.

Do not fully tighten the Screws.


Step 10



Upside down Chair and rotate the turntable (J) 90° as shown in the image.
With assistance from your adult partner, attach the Turntable (J) to the Support Seat Panel (E) using Screws (①) with Allen Wrench (④) as shown above.

Fully tighten the Screws.

Step 11



Inspect the Chair and make sure all parts are adequately connected.
Then EXERT pressure, floorwards onto the Chair with both hand
This pressure will help align all parts at all joints.
In a sequential manner, tighten all Bolts and Screws at all joints.


CAUTION: When tightening these Bolts, tighten sequentially.

DO NOT tighten any bolt fully and then move towards the next one.

This would cause the frame to warp.

WARNING!! IF THE CHAIR IS NOT STABLE , IT COULD LEAD TO DAMAGING THE PRODUCT.

Step 12



Place the Seat Cushion (K), then the Back Cushions (L) onto the Chair.
Then affix the "magic tape straps" around the Chair as shown above.
Your Chair is ready to be used.
This Chair can only be used on a flat, level surface.

Step 13

