casualcontemporaryliving

Assembly instructions



CUSTOMER SERVICE QUESTION & INFORMATION


For missing hardware, damaged parts, or questions concerning assembly please contact below rather than your store or on-line provider. Replacement parts are usually available within 2-3 days.



casualcontemporaryliving

ASSEMBLY INSTRUCTIONS

Place all parts on a clean and soft surface such as a rug or carpet to avoid scratching during assembly. Please follow all assembly instructions step by step. It is best to use a screwdriver as opposed to a drill during assembly to avoid over tightening or striping screws/bolts.



CUSTOMER SERVICE QUESTION & INFORMATION

For missing hardware, damaged parts, or questions concerning assembly please contact below rather than your store or on-line provider. Replacement parts are usually available within 2-3 days.

HARDWARE LIST:

PARTS LIST:

CODE	PICTURE	DESCRIPTION	QTY
A		BOLT	1
В		WRENCH	1
С	\bigcirc	PVC WASHER	2

CODE	DESCRIPTION	QTY
1	LEGS	04
2	LOWER LEG BLOCK	01
3	BOTTOM POST	01
4	MIDDLE POST	01
5	TOP POST	01
6	PEGS	08

