


INSTRUCTION MANUAL



37" X 71" Rectangular Dining Table


V2.0

! NOTICE

Do not overtighten screws. (Insert all screws before tightening screws.)

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws, and nuts before use.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Please adjust the speed slowly when you use electric drill for assembling to avoid screw slippage.

TOOLS REQUIRED



**TABLE
330 LBS
CAPACITY**




**1 PERSON
ASSEMBLY**




**UP TO 30 MIN.
ASSEMBLY**

HARDWARE




PARTS



PRODUCT ASSEMBLY - OVERALL VIEW


Look at following overall view of this table and exact position of each part to be assembled.



PRODUCT ASSEMBLY

1


Attach **Part C Table Leg** to **Part A Table Top** with 16 pcs of **Hardware #2 Bolt**, **Hardware #4 M6 Nut** and **Hardware #5 M6 Washer**.



PRODUCT ASSEMBLY


2

Attach **Part D Side Rail** between 2 pcs of **Part C Table Leg** with 16 pcs of **Hardware #3 Bolt**.



3

Attach **Part B Table Bottom Feet** to **Part C Table Leg** with 16 pcs of **Hardware #1 Screw**.




PRODUCT ASSEMBLY

4

Check and tighten all the bolts and screws again to finish the assembly.

Remark: Please remove the umbrella hole cover when you insert the umbrella!



CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the furniture with a damp cloth.

Regular cleaning not only preserves the aesthetic appeal of your furniture, but also helps extend its lifespan.