


## Product Structure



### **Attentions**

- Do not block the air inlet and outlet during use!
- Do not fill the container with water, only put the entire bottle of red wine into refrigeration!
- Please use with a dedicated adapter, do not use non-dedicated adapters!
- Do not immerse the entire machine in water for cleaning, only use a damp towel to clean the surface!
- **Warm Tips:** This product is not suitable for Champagne

## Warranty Instructions

Sincerely appreciate you for choosing to use our company's intelligent red wine freezing machine. The main machine is guaranteed for one year from the date of purchase, and damaged parts are not covered by the warranty. During the warranty period, any faults caused by the machine's own quality under normal use shall be repaired.

### Fault Analysis Table for Red Wine Freezing Machine

| Name              | Fault Phenomenon  |
|-------------------|---|
| Smart Wine Cooler | <ul style="list-style-type: none"><li>• Screen does not light;</li><li>• Uncooled;</li><li>• No response from touch buttons;</li><li>• The display shows, but the product doesn't work.</li></ul> |

### Below Situations Are Not Included In Warranty

1. Have no valid purchase certificate and warranty card.
2. Shell damage or physical damage by human.
3. Fall, extrusion, soaking, damp or other human-caused damages.
4. Damage by natural disasters like flood, fire and lighting stroke.



If you have any problems during use, please feel free to contact us: [service@yeegolife.com](mailto:service@yeegolife.com); rest assured, we will do our best to solve the problems you encounter.

 <https://yeegolife.com>

Yeego

LET'S YEEGO

# Smart Wine Cooler

## USER MANUAL

Before use, please read and follow all safety rules and operation instructions.




## Working Principle

Thank you very much for choosing our intelligent red wine freezer. Our product adopts the world's leading thermoelectric refrigeration technology. With the advantages of fast cooling speed, high efficiency, low energy consumption, small volume, and no pollution, the freezer can be placed in family living rooms, cafes, RVs, yachts, outdoor camping and other environments. By adopting variable frequency temperature control technology, precise temperature control and fast cooling, the freezer can meet the optimal taste temperature requirements of different red wines!


## Accessory Description

Including:

- Machine x 1
- Home adapter x 1
- Water pan x 1
- User manual x 1




1. Wine freezer host



2. User Manual



3. Water Pan



4. Home Adapter

## Specification

|                         |                 |
|-------------------------|-----------------|
| Name: Smart Wine Cooler | Model: BK-JC01  |
| Input: DC-12V           | Power: 36W      |
| Size: 8.5×5.9×9.2 inch  | Weight: 3.97 lb |

## Installation Steps




**1**  
Connect the DC head of the power adapter to the host and plug the power adapter into the power supply.

**2**  
Put the water tray into the bottom of the host, gently press the top cover switch to open the top cover, and put the wine into the refrigerated bin.

**3**  
Select the wine/cold drink mode and set the desired temperature to start the refrigeration!

## Operation Instruction



| Button                                       | Function   |
|--|--|
| <b>Ambient Light Switch</b>                  | When the machine is plugged in, the light is on indicating that the machine is ready to operate. You can switch the light off by pressing the Ambient Light Switch.  |
| <b>Mode Selection (Part 1)</b>               | Press the Mode Selection Button once to turn on the machine or enter Standby Mode.<br><b>Standby Mode:</b> No icon will light up and only the current temperature of the machine will be displayed.  |
| <b>Mode Selection (Part 2)</b>               | <b>Red Wine Mode:</b> When the device is in standby mode, press the Mode Selection Button once. After 3 seconds, the machine will beep, indicating that it will now operate in this mode. The Red Wine Mode Light will stay on. The default temperature will be set at 53°F/12°C, which can be adjusted as desired by using temp changing button.<br><b>Cold Drink Mode:</b> When the device is in standby mode, press the Mode Selection Button twice. After 3 seconds, the machine will beep, indicating that it operates in the selected mode. The Cold Drink Mode Light will stay on. The default temperature will be set at 41°F /5°C, which can be adjusted as desired by using temperature changing buttons.<br><b>Mode Switch:</b> When the device is in Red Wine/Cold Drink Mode and you want to choose other modes, press the Mode Selection Button for 3 seconds and as you hold the button, the corresponding mode icon will start blinking. Press the Mode Selection Button again to switch to your desired mode.<br><b>Shutdown:</b><br><b>In Red Wine/Cold Drink Mode:</b> press the Mode Selection Button for 3 seconds (corresponding mode icon will start blinking), then long press the Mode Selection Button for 3 seconds and the machine will automatically shut down.<br><b>In Standby Mode:</b> Long press the Mode Selection Button for 3 seconds and the machine will shut down. |
| <b>Temperature Changing</b>                  | When the device is in Red Wine/Cold Drink Mode and you want to adjust the temperature, press the Mode Selection Button for 3 seconds and as you hold the button, the corresponding mode icon will start blinking. Then press Temperature Changing Buttons to adjust to the desired temperature.<br><b>Red Wine Mode:</b> 46°F-64°F/8°C-18°C.<br><b>Cold Drinks Mode:</b> 23°F-68°F/-5°C-20°C.  |
| <b>Switch between Fahrenheit and Celsius</b> | Press the Ambient Light Switch and Mode Selection at the same time for 3 seconds to switch the Temperature Display from Fahrenheit (°F) to Celsius (°C) or vice versa.   |