



Kindly Remind



It is not easy to meet each other in such a big world Thank You for Your Purchase!

Dear Valued Customer,

If you encounter any issues, please contact us. Our support team is here to help.

E-mail us via : assemblehelp@163.com

Text us via : 9153393399

Please provide us below information when you contact us:

- 1. Purchase order number and platform
- 2. Problem details(including damage or missing parts number, problem picture)

Response Hours: In 24 hours

Return policy:

- 1. Save time and money: Don't return the product without contacting US
- 2. Don't open all packages if returning, use the original package for return
- 3. For quality issues, provide images or videos for a quick solution within 24 hours.

Easier Installation help:please use your mobile browser to scan the QR code below to watch the installation video.(Outdoor Chaise SKU : 4001)



ASSEMBLY INSTRUCTIONS

Thank you for choosing our product!



Notice:

1.50% Tighten before fixing all screws, allen wrench is recommended instead of an electric drill,

2. Place the item on a flat ground to adjust and make sure it remains stable,

3. Tighten up all screws with tools gradually,

4. If the screws are not aligned with holes during assembly, please loosen 5. If the item is not stable, please loosen all the screw, adjust it on a flat ground and tighten up all screws again,

6.Note: If one or some screws are fully tightened during assembly, chances are the others will not be aligned with holes. In addition all the holes are designed to be relatively larger to provide more space for the adjustment of the screws.







